



***XVZ1300TF***

**OWNER'S MANUAL**





Welcome to the Yamaha world of motorcycling!

As the owner of a Royal Star™ VENTURE®, you are benefiting from Yamaha's vast experience and newest technology regarding the design and manufacture of high-quality products, which have earned Yamaha a reputation for dependability.

Please take the time to read this manual thoroughly, so as to enjoy all advantages of your Royal Star™ VENTURE®. The owner's manual does not only instruct you in how to operate, inspect and maintain your motorcycle, but also in how to safeguard yourself and others from trouble and injury.

In addition, the many tips given in this manual will help keep your motorcycle in the best possible condition. If you have any further questions, do not hesitate to contact your Yamaha dealer.

The Yamaha team wishes you many safe and pleasant rides. So, remember to put safety first!

# IMPORTANT MANUAL INFORMATION

---

---

Particularly important information is distinguished in this manual by the following notations:



The Safety Alert Symbol means **ATTENTION! BECOME ALERT! YOUR SAFETY IS INVOLVED!**



Failure to follow **WARNING** instructions could result in severe injury or death to the motorcycle operator, a bystander, or a person inspecting or repairing the motorcycle.

**CAUTION:**

A **CAUTION** indicates special precautions that must be taken to avoid damage to the motorcycle.

**NOTE:**

A **NOTE** provides key information to make procedures easier or clearer.

**NOTE:**

- This manual should be considered a permanent part of this motorcycle and should remain with it even if the motorcycle is subsequently sold.
  - Yamaha continually seeks advancements in product design and quality. Therefore, while this manual contains the most current product information available at the time of printing, there may be minor discrepancies between your motorcycle and this manual. If you have any questions concerning this manual, please consult your Yamaha dealer.
-

# IMPORTANT MANUAL INFORMATION

---

---

 **WARNING**

**PLEASE READ THIS MANUAL CAREFULLY AND COMPLETELY BEFORE OPERATING THIS MOTORCYCLE.**

---

# **IMPORTANT MANUAL INFORMATION**

---

---

**XVZ1300TF**

**OWNER'S MANUAL**

**© 2000 by Yamaha Motor Co., Ltd.**

**1st Edition, November 2000**

**All rights reserved.**

**Any reprinting or unauthorized use  
without the written permission of  
Yamaha Motor Co., Ltd.  
is expressly prohibited.**

**Printed in Japan.**

# TABLE OF CONTENTS

---

---

1 GIVE SAFETY THE RIGHT OF WAY	1
2 DESCRIPTION	2
3 INSTRUMENT AND CONTROL FUNCTIONS	3
4 AUDIO SYSTEM	4
5 PRE-OPERATION CHECKS	5
6 OPERATION AND IMPORTANT RIDING POINTS	6
7 PERIODIC MAINTENANCE AND MINOR REPAIR	7
8 MOTORCYCLE CARE AND STORAGE	8
9 SPECIFICATIONS	9
10 CONSUMER INFORMATION	10
INDEX	







# GIVE SAFETY THE RIGHT OF WAY

---

---

GIVE SAFETY THE RIGHT OF WAY ..... 1-1



# GIVE SAFETY THE RIGHT OF WAY

---

---

Motorcycles are fascinating vehicles, which can give you an unsurpassed feeling of power and freedom. However, they also impose certain limits, which you must accept; even the best motorcycle does not ignore the laws of physics.

Regular care and maintenance are essential for preserving value and operating condition of your motorcycle. Moreover, what is true for the motorcycle is also true for the rider: good performance depends on being in good shape. Riding under the influence of medication, drugs and alcohol is, of course, out of the question. Motorcycle riders—more than car drivers—must always be at their mental and physical best. Under the influence of even small amounts of alcohol, there is a tendency to take dangerous risks.

Protective clothing is as essential for the motorcycle rider as seat belts are for car drivers and passengers. Always wear a complete motorcycle suit (whether made of leather or tear-resistant synthetic materials with protectors), sturdy boots, motorcycle gloves and a properly fitting helmet. Optimum protective wear, however, should not encourage carelessness. Although full-coverage helmets and suits, in particular, create an illusion of total safety and protection, motorcyclists will always be vulnerable. Riders who lack critical self-control run the risk of going too fast and are apt to take chances. This is even more dangerous in wet weather. The good motorcyclist rides safely, predictably and defensively—avoiding all dangers, including those caused by others.


Enjoy your ride!

Left view .....	2-1
Right view.....	2-2
Controls and instruments .....	2-3

# DESCRIPTION

## Left view

2




- 1. Shift pedal
- 2. Starter (choke) knob
- 3. Fuel tank cap
- 4. Fuel cock
- 5. Battery
- 6. Fuse box 2

- (page 3-10)
- (page 3-14)
- (page 3-11)
- (page 3-13)
- (page 7-32)
- (page 7-34)

- 7. Side case
- 8. Helmet holder
- 9. License light
- 10. Tail/brake light
- 11. Rear turn signal lights

- (page 3-17)
- (page 3-15)
- (page 7-37)
- (page 7-36)
- (page 7-36)

## Right view




- |                                       |             |                                   |             |
|---------------------------------------|-------------|-----------------------------------|-------------|
| 12. Muffler                           |             | 21. Headlight                     | (page 7-35) |
| 13. Owner's tool kit                  | (page 7-1)  | 22. Front turn signal lights      | (page 7-36) |
| 14. Helmet holder                     | (page 3-15) | 23. Fuse box 1                    | (page 7-33) |
| 15. Travel trunk                      | (page 3-17) | 24. Brake pedal                   | (page 3-11) |
| 16. Passenger seat                    |             | 25. Engine oil level check window | (page 7-12) |
| 17. Shock absorber assembly air valve | (page 3-20) | 26. Rider footrest                |             |
| 18. Rider seat                        | (page 3-15) | 27. Coolant reservoir             | (page 7-15) |
| 19. Fuel tank                         | (page 3-12) | 28. Passenger footrest            |             |
| 20. Front fork air valve              | (page 3-19) |                                   |             |

# DESCRIPTION

---

## Controls and instruments

2




- |                              |             |                              |             |
|------------------------------|-------------|------------------------------|-------------|
| 1. Clutch lever              | (page 3-10) | 6. Main switch/steering lock | (page 3-1)  |
| 2. Audio system control unit | (page 4-3)  | 7. Right handlebar switches  | (page 3-9)  |
| 3. Left handlebar switches   | (page 3-9)  | 8. Throttle grip             | (page 7-21) |
| 4. Rider headset jack        | (page 4-2)  | 9. Brake lever               | (page 3-11) |
| 5. Speedometer unit          | (page 3-5)  |                              |             |

# INSTRUMENT AND CONTROL FUNCTIONS

Main switch/steering lock .....	3-1	Fuel tank breather hose .....	3-13
Indicator and warning lights .....	3-3	Fuel cock .....	3-13
Speedometer unit .....	3-5	Starter (choke) knob .....	3-14
Cruise control system .....	3-6	Locking the steering with a padlock .....	3-14
Fuel gauge .....	3-8	Rider seat .....	3-15
Anti-theft alarm (optional) .....	3-8	Helmet holders .....	3-15
Handlebar switches .....	3-9	Side cases and travel trunk .....	3-16
Clutch lever .....	3-10	Adjusting the front fork .....	3-19
Shift pedal .....	3-10	Adjusting the shock absorber assembly .....	3-20
Brake lever .....	3-11	Sidestand .....	3-21
Brake pedal .....	3-11	Ignition circuit cut-off system .....	3-22
Fuel tank cap .....	3-11	Auxiliary DC jack and terminals .....	3-24
Fuel .....	3-12		

# INSTRUMENT AND CONTROL FUNCTIONS

3



1. ON
2. ACC (Accessory)
3. OFF
4. LOCK
5. P (Parking)

## Main switch/steering lock

The main switch/steering lock controls the ignition and lighting systems, and is used to lock the steering. The various positions are described below.

### ON

All electrical systems are supplied with power, and the engine can be started. The key cannot be removed.


### ACC (Accessory)

The audio system and the auxiliary DC jack and terminals can be used in this position. Therefore, do not use the accessory position for an extended period of time, otherwise the battery may discharge.

The key cannot be removed.

### OFF

All electrical systems are off. The key can be removed.



### LOCK

The steering is locked, and all electrical systems are off. The key can be removed.

### To lock the steering


1. Turn the handlebars all the way to the left.
2. Push the key in from the “OFF” position, and then turn it to “LOCK” while still pushing it.
3. Remove the key.

### To unlock the steering

Push the key in, and then turn it to “OFF” while still pushing it.



# INSTRUMENT AND CONTROL FUNCTIONS



1. Push.
2. Turn.

## **! WARNING**

Never turn the key to “OFF” or “LOCK” while the motorcycle is moving, otherwise the electrical systems will be switched off, which may result in loss of control or an accident. Make sure that the motorcycle is stopped before turning the key to “OFF” or “LOCK”.


## **P (Parking)**

The steering is locked, and the taillight, license light and auxiliary light are on, but all other electrical systems are off. The key can be removed. The steering must be locked before the key can be turned to “P”.

## **CAUTION:**

**Do not use the parking position for an extended length of time, otherwise the battery may discharge.**

# INSTRUMENT AND CONTROL FUNCTIONS



3

## Indicator and warning lights

### 1. Turn signal indicator lights

“↵” / “⇨”

The corresponding indicator light flashes when the turn signal switch is pushed to the left or right.

### 2. High beam indicator light “≡⊙”

This indicator light comes on when the high beam of the headlight is switched on.

### 3. Oil level warning light “”

This warning light comes on when the engine oil level is low.

The electrical circuit of the warning light can be checked according to the following procedure.

1. Set the engine stop switch to “○” and turn the key to “ON”.
2. Shift the transmission into the neutral position or pull the clutch lever.
3. Push the start switch. If the warning light does not come on while pushing the start switch, have a Yamaha dealer check the electrical circuit.

## NOTE:

Even if the oil level is sufficient, the warning light may flicker when riding on a slope or during sudden acceleration or deceleration, but this is not a malfunction.

### 4. Overdrive indicator light “O/D”

This indicator light comes on when the transmission is in overdrive (5th gear).

### 5. Engine trouble warning light

“”

This warning light comes on or flashes when an electrical circuit monitoring the engine is defective. When this occurs, have the Yamaha dealer check the self-diagnosis system.

## 6. Fuel level warning light “”

This warning light comes on when the fuel level drops below approximately 3.5 L. When this occurs, turn the fuel cock lever to the “RES” position and re-fuel as soon as possible.

## 7. Cruise control indicator lights

See page 3-6 for an explanation of these indicator lights.


## 8. Neutral indicator light “N”

This indicator light comes on when the transmission is in the neutral position.

## 9. Coolant temperature warning light “”

This warning light comes on when the engine overheats. When this occurs, stop the engine immediately and allow the engine to cool.

The electrical circuit of the warning light can be checked according to the following procedure.


1. Set the engine stop switch to “” and turn the key to “ON”.
2. Shift the transmission into the neutral position or pull the clutch lever.
3. Push the start switch. If the warning light does not come on while pushing the start switch, have a Yamaha dealer check the electrical circuit.

### CAUTION:

**Do not operate the engine if it is overheated.**

# INSTRUMENT AND CONTROL FUNCTIONS

3



1. Speedometer
2. Odometer/tripmeters/clock
3. "RESET" button
4. "SELECT" button

## Speedometer unit

The speedometer unit is equipped with the following:

- a digital speedometer (which shows riding speed)
- an odometer (which shows the total distance traveled)
- two tripmeters (which show the distance traveled since they were last set to zero)
- a fuel reserve tripmeter (which shows the distance traveled on the fuel reserve)
- a clock

## Odometer and tripmeter modes

Pushing the "SELECT" button switches the display between the odometer mode "ODO" and the tripmeter modes "TRIP 1" and "TRIP 2" in the following order:

ODO → TRIP 1 → TRIP 2 → ODO

If the fuel level warning light comes on (see page 3-4), the odometer display will automatically change to the fuel reserve tripmeter mode "TRIP F" and start counting the distance traveled from that point. In that case, pushing the "SELECT" button switches the display between the various tripmeter and odometer modes in the following order: TRIP F → TRIP 1 → TRIP 2 → ODO → TRIP F

To reset a tripmeter, select it by pushing the "SELECT" button, and then push the "RESET" button. If you do not reset the fuel reserve tripmeter manually, it will reset itself automatically and the display will return to "TRIP 1" after refueling and traveling 5 km.

## NOTE:

After resetting the fuel reserve tripmeter, the display will return to "TRIP 1", unless a different mode had been previously selected; in that case, the display automatically returns to the prior mode.

## Clock mode

To change the display to the clock mode, push both the "SELECT" and "RESET" buttons.

To change the display back to the odometer modes, push the "SELECT" button.

To set the clock:

1. Push both the “SELECT” and “RESET” buttons for at least two seconds.
2. When the hour digits start flashing, push the “RESET” button to set the hours.
3. Push the “SELECT” button, and the minute digits will start flashing.
4. Push the “RESET” button to set the minutes.
5. Push the “SELECT” button to start the clock.

**NOTE:** \_\_\_\_\_

After setting the clock, be sure to push the “SELECT” button before turning the key to “OFF”, otherwise the clock will not be set.


---

## Cruise control system

This motorcycle is equipped with a cruise control system designed to maintain a set traveling speed.

### Activating and setting the cruise control system

The cruise control system can only be activated when riding in 4th or 5th gear at speeds between 50 km/h and 130 km/h.




1. “CRUISE” switch

To activate and set the cruise control system:


1. Push the “CRUISE” switch to the left. The “ON” indicator light will come on.

# INSTRUMENT AND CONTROL FUNCTIONS

3



1. Cruise control switch
  2. "CANCEL" switch
2. Press the "SET/DEC" (set/decelerate) side of the cruise control switch to activate the cruise control system. The "SET" indicator light comes on.
  3. Set the desired traveling speed as follows. Press the "RES/ACC" (resume/accelerate) side of the cruise control switch to increase the set speed or the "SET/DEC" side to decrease the speed.



1. "SET" indicator light
2. "RES" indicator light
3. "ON" indicator light

**NOTE:** Pressing the cruise control switch once will change the speed in increments of 1.6 km/h. Holding the cruise control switch down will increase or decrease the speed continuously until the switch is released.

The traveling speed can be set to a maximum of 130 km/h and a minimum of 50 km/h.

When the cruise control system is activated and the throttle grip is turned to increase the speed by up to 8 km/h, the cruise control system will return to the

set speed after the throttle grip is released. However, if the speed is increased by more than 8 km/h, the cruise control system will be deactivated until the traveling speed is within 8 km/h of the set speed.

## Deactivating the cruise control system

Applying the front or rear brake or disengaging the clutch will automatically deactivate the cruise control system. Push the "CANCEL" switch to manually deactivate cruise control.

- NOTE:**
- When the cruise control system is deactivated, the "RES" (resume) indicator light will come on.
  - Traveling speed decreases as soon as the cruise control system is deactivated; unless the throttle grip is turned.


# INSTRUMENT AND CONTROL FUNCTIONS

Push the “RES/ACC” side of the cruise control switch to reactivate the system. The traveling speed will return to the previously set speed. The “RES” indicator light will flash during this time and then go off. Once the cruise control system is reactivated, the “SET” indicator light will come on.

Push the “CRUISE” switch to the right to turn the cruise control system off completely.

## **WARNING**

**If the cruise control system is defective, the “SET” and “RES” indicator lights will flash simultaneously. If this occurs, turn the cruise control system off and have a Yamaha dealer check it.**



1. Fuel gauge

## Fuel gauge

The fuel gauge indicates the amount of fuel in the fuel tank. The display segments of the fuel gauge disappear towards “E” (Empty) as the fuel level decreases. When only one segment is left near “E”, refuel as soon as possible.

## NOTE: \_\_\_\_\_


This fuel gauge is equipped with a self-diagnosis system. If the electrical circuit is defective, first the display segments and then either “E” or “F” will flash. If this occurs, have a Yamaha dealer check the electrical circuit.

## Anti-theft alarm (optional)

This motorcycle can be equipped with an optional anti-theft alarm by a Yamaha dealer. Contact a Yamaha dealer for more information.

# INSTRUMENT AND CONTROL FUNCTIONS

3



## Handlebar switches

### 1. Pass switch “≡D”

Press this switch to flash the headlight.

### 2. Dimmer switch “≡D / ≡D”


Set this switch to “≡D” for the high beam and to “≡D” for the low beam.

### 3. Turn signal switch “↔/↔”

To signal a right-hand turn, push this switch to “↔”. To signal a left-hand turn, push this switch to “↔”. When released, the switch returns to the center position. To cancel the turn signal lights, push the switch in after it has returned to the center position.

### 4. Horn switch “📣”

Press this switch to sound the horn.



### 5. Engine stop switch “○/⊗”

Set this switch to “○” before starting the engine. Set this switch to “⊗” to stop the engine in case of an emergency, such as when the motorcycle overturns or when the throttle cable is stuck.

### 6. Light switch “☀ / ≡D ⊕ / ●”

Set this switch to “≡D ⊕” to turn on the auxiliary light, meter lighting, taillight and license plate light. Set the switch to “☀” to turn on the headlight also. Set the switch to “●” to turn off all the lights.



# INSTRUMENT AND CONTROL FUNCTIONS

## 7. Cruise control switches


See page 3-6 for an explanation of the cruise control system.

## 8. Start switch “”

Push this switch to crank the engine with the starter.

### **CAUTION:**

**See page 6-1 for starting instructions prior to starting the engine.**




1. Clutch lever

### **Clutch lever**

The clutch lever is located at the left handlebar grip. To disengage the clutch, pull the lever toward the handlebar grip. To engage the clutch, release the lever. The lever should be pulled rapidly and released slowly for smooth clutch operation.

The clutch lever is equipped with a clutch switch, which is part of the ignition circuit cut-off system. (See page 3-22 for an explanation of the ignition circuit cut-off system.)



1. Shift pedal

### **Shift pedal**


The shift pedal is located on the left side of the engine and is used in combination with the clutch lever when shifting the gears of the 5-speed constant-mesh transmission equipped on this motorcycle.

### **NOTE:**

Use your toes or heel to shift up and your toes to shift down.

# INSTRUMENT AND CONTROL FUNCTIONS


3



1. Brake lever

## Brake lever


The brake lever is located at the right handlebar grip. To apply the front brake, pull the lever toward the handlebar grip.



1. Brake pedal

## Brake pedal

The brake pedal is on the right side of the motorcycle. To apply the rear brake, press down on the brake pedal.



1. Fuel tank cap lock cover  
2. Unlock.

## Fuel tank cap

### To remove the fuel tank cap

Slide the lock cover open, insert the key into the lock, and then turn it 1/4 turn clockwise. The lock will be released and the fuel tank cap can be removed.

### To install the fuel tank cap

1. Insert the fuel tank cap into the tank opening with the key inserted in the lock and with the “△” mark facing forward.


# INSTRUMENT AND CONTROL FUNCTIONS

2. Turn the key counterclockwise to the original position, remove it, and then close the lock cover.

**NOTE:** \_\_\_\_\_  
The fuel tank cap cannot be installed unless the key is in the lock. In addition, the key cannot be removed if the cap is not properly installed and locked.

**⚠ WARNING** \_\_\_\_\_

**Make sure that the fuel tank cap is properly installed before riding.**



1. Fuel tank filler tube
2. Fuel level

## Fuel

Make sure that there is sufficient fuel in the tank. Fill the fuel tank to the bottom of the filler tube as shown.

**⚠ WARNING** \_\_\_\_\_

- Do not overfill the fuel tank, otherwise it may overflow when the fuel warms up and expands.
- Avoid spilling fuel on the hot engine.

**CAUTION:** \_\_\_\_\_

Immediately wipe off spilled fuel with a clean, dry, soft cloth, since fuel may deteriorate painted surfaces or plastic parts.

Recommended fuel:

Regular unleaded gasoline with a research octane number of 91 or higher

Fuel tank capacity:

Total amount:

22.5 L


Reserve amount:

3.5 L

**NOTE:** \_\_\_\_\_

If knocking (or pinging) occurs, use gasoline of a different brand or with a higher octane grade.

# INSTRUMENT AND CONTROL FUNCTIONS




1. Fuel tank breather hose

## Fuel tank breather hose

Before operating the motorcycle:

- Check the fuel tank breather hose connection.
- Check the fuel tank breather hose for cracks or damage, and replace it if damaged.
- Make sure that the end of the fuel tank breather hose is not blocked, and clean it if necessary.




## Fuel cock

The fuel cock supplies fuel from the tank to the carburetors while also filtering it.

The fuel cock lever positions are explained as follows and shown in the illustrations.

### OFF

With the fuel cock lever in this position, fuel will not flow. Always turn the fuel cock lever to this position when the engine is not running.




### ON

With the fuel cock lever in this position, fuel flows to the carburetors. Turn the fuel cock lever to this position when starting the engine and riding.


# INSTRUMENT AND CONTROL FUNCTIONS

**RES: reserve position**



## RES

This indicates reserve. With the fuel cock lever in this position, the fuel reserve is made available. Turn the fuel cock lever to this position if you run out of fuel while riding. When this occurs, refuel as soon as possible and be sure to turn the fuel cock lever back to “ON”!




1. Starter (choke) knob “|↘|”

## Starter (choke) knob “|↘|”

Starting a cold engine requires a richer air-fuel mixture, which is supplied by the starter (choke).

Move the knob in direction @ to turn on the starter (choke).

Move the knob in direction (b) to turn off the starter (choke).




## Locking the steering with a padlock

In addition to the main switch/steering lock, there are brackets on the right side of the steering head pipe for locking the steering with a padlock. To do so, turn the handlebar until the holes in the two brackets are aligned, and then lock the steering with a suitable padlock.

# INSTRUMENT AND CONTROL FUNCTIONS

3




1. Nut (× 2)

## Rider seat

### To remove the rider seat

Remove the nuts, and then pull the rider seat up.




1. Projection  
2. Seat holder

### To install the rider seat

Insert the projection on the rear of the rider seat into the seat holder as shown, place the seat in the original position, and then tighten the nuts.

### NOTE:

Make sure that the rider seat is properly secured before riding.




1. Helmet holder (right)  
2. Unlock.

## Helmet holders

### To open a helmet holder

Insert the key into the helmet holder lock, and then turn it as shown.



1. Helmet holder (left)
2. Unlock.

## To close a helmet holder

Place the helmet holder in the original position, and then remove the key.

### **! WARNING**

Never ride with a helmet attached to a helmet holder, since the helmet may hit objects, causing loss of control and possibly an accident.

## Side cases and travel trunk

### **! WARNING**


Improper loading or overloading can cause loss of control and possibly an accident or personal injury. See page 7-21 for important loading and tire pressure information.

- Always securely close the side cases and travel trunk before riding.
- Distribute weight evenly on each side of the motorcycle.
- Do not exceed the load limit of 9 kg for each side case and the travel trunk.
- Do not exceed the maximum load of 190 kg for the vehicle.

- Do not exceed 120 km/h when riding with the travel trunk, side cases or both installed, otherwise handling could be affected. Improper loading, poor tire or overall motorcycle conditions, poor road surfaces or adverse weather conditions may make it necessary to further reduce the riding speed.

# INSTRUMENT AND CONTROL FUNCTIONS

3




1. Side case lock
2. Unlock.

## Side cases

### To open a side case

1. Insert the key into the lock, turn it counterclockwise, and then push it in.



1. Main storage area
2. Storage pouch


2. Fold the side case lid up.

### To close a side case

1. Fold the side case lid down.
2. Turn the key clockwise, and then remove it.

## **NOTE:**

Push both sides of the lid down so that both latches snap into place.



1. Travel trunk lock
2. Unlock.


## Travel trunk

### To open the travel trunk

1. Insert the key into the lock, turn it counterclockwise, and then push it in.



# INSTRUMENT AND CONTROL FUNCTIONS




1. Travel trunk lid resting in opened position
2. Storage pouch

2. Fold the travel trunk lid up, and then release it so that it will rest in place as shown.


**CAUTION:** \_\_\_\_\_

**Do not apply excessive pressure on the travel trunk lid when it is open.**



To close the travel trunk

1. Fold the travel trunk lid up completely, and then fold it down.



**NOTE:** \_\_\_\_\_

Push both sides of the lid down so that both latches snap into place.

2. Turn the key clockwise, and then remove it.

**CAUTION:** \_\_\_\_\_

**To avoid locking the key in, never lock either side case or the travel trunk and remove the key from the lock before closing the lid.**

# INSTRUMENT AND CONTROL FUNCTIONS

## Adjusting the front fork

This front fork is equipped with air valves for adjusting the spring rate.

### **⚠ WARNING**


**Always adjust both fork legs equally, otherwise poor handling and loss of stability may result.**

Adjust the spring rate as follows.

1. Place the motorcycle on the side-stand.

### **NOTE:**

When checking and adjusting the air pressure, there should be no weight on the motorcycle.



1. Front fork air valve cap
2. Remove the air valve cap from each fork leg.
3. Check the air pressure in each fork leg with the air pressure gauge included in the owner's tool kit.
4. To increase the spring rate and thereby harden the suspension, increase the air pressure with an air pump. To decrease the spring rate and thereby soften the suspension, decrease the air pressure by pushing each valve stem down.

Spring rate:

Minimum (soft):

Air pressure =  
0 kPa (0 kgf/cm<sup>2</sup>, 0 bar)

Standard:

Air pressure =  
0 kPa (0 kgf/cm<sup>2</sup>, 0 bar)

Maximum (hard):

Air pressure =  
50 kPa (0.5 kgf/cm<sup>2</sup>, 0.5 bar)

### **CAUTION:**

**Never exceed the maximum air pressure, otherwise the front fork oil seals may become damaged.**

5. Securely install the air valve caps.

# INSTRUMENT AND CONTROL FUNCTIONS

## Adjusting the shock absorber assembly

This shock absorber assembly is equipped with an air valve for adjusting the spring rate.

### CAUTION:


**Never attempt to turn an adjusting mechanism beyond the maximum or minimum settings.**

Adjust the spring rate as follows.

1. Place the motorcycle on the sidestand.

### NOTE:

When checking and adjusting the air pressure, there should be no weight on the motorcycle.



1. Shock absorber assembly air valve cap
2. Remove the air valve cap.
3. Check the air pressure with the air pressure gauge included in the owner's tool kit.
4. To increase the spring rate and thereby harden the suspension, increase the air pressure with an air pump. To decrease the spring rate and thereby soften the suspension, decrease the air pressure by pushing the valve stem down.

Spring rate:

Minimum (soft):

Air pressure =  
0 kPa (0 kgf/cm<sup>2</sup>, 0 bar)

Standard:

Air pressure =  
0 kPa (0 kgf/cm<sup>2</sup>, 0 bar)

Maximum (hard):

Air pressure =  
400 kPa (4.0 kgf/cm<sup>2</sup>, 4.0 bar)

# INSTRUMENT AND CONTROL FUNCTIONS

---

---

## **CAUTION:** \_\_\_\_\_

**Never exceed the maximum air pressure, otherwise the oil seal may become damaged.**

---

5. Securely install the air valve cap.

## **Sidestand**

The sidestand is located on the left side of the frame. Raise the sidestand or lower it with your foot while holding the motorcycle upright.

## **NOTE:** \_\_\_\_\_

The built-in sidestand switch is part of the ignition circuit cut-off system, which cuts the ignition in certain situations. (See further down for an explanation of the ignition circuit cut-off system.)

---

## **! WARNING** \_\_\_\_\_

**The motorcycle must not be ridden with the sidestand down, or if the sidestand cannot be properly moved up (or does not stay up), otherwise the sidestand could contact the ground and distract the operator, resulting in a possible loss of control. Yamaha's ignition circuit cut-off system has been designed to assist the operator in fulfilling the responsibility of raising the sidestand before starting off. Therefore, check this system regularly as described below and have a Yamaha dealer repair it if it does not function properly.**

---

## Ignition circuit cut-off system

The ignition circuit cut-off system (comprising the sidestand switch, clutch switch and neutral switch) has the following functions.

- It prevents starting when the transmission is in gear and the sidestand is up, but the clutch lever is not pulled.
- It prevents starting when the transmission is in gear and the clutch lever is pulled, but the sidestand is still down.
- It cuts the running engine when the transmission is in gear and the sidestand is moved down.

Periodically check the operation of the ignition circuit cut-off system according to the following procedure.


### **WARNING**


**If a malfunction is noted, have a Yamaha dealer check the system before riding.**

---


# INSTRUMENT AND CONTROL FUNCTIONS

3





1. Auxiliary DC jack



1. Auxiliary DC terminal

## Auxiliary DC jack and terminals

12-V accessories connected to the auxiliary DC jack at the front and auxiliary DC terminals under the rider seat can be used when the key is in the “ACC” or “ON” position.

### CAUTION:

The accessories connected to the auxiliary DC jack and terminals should not be used with the engine turned off, and their combined load must never exceed 5 A or 60 W, otherwise the battery may discharge.

### ⚠ WARNING

To prevent electrical shock or short-circuiting, make sure that the caps are installed when the auxiliary DC jack and terminals are not being used.







Location of parts .....	4-1
Headsets (optional) .....	4-2
Control unit .....	4-3
Making basic settings .....	4-5
Making mode settings .....	4-5
Cassette deck operation .....	4-9
Radio operation .....	4-12
Optional CD changer operation .....	4-17
Auxiliary audio source operation .....	4-18

# AUDIO SYSTEM

## Location of parts



1. Audio system control unit
2. Front speaker (× 2)
3. Rider headset jack
4. Cassette deck lid
5. Main switch/steering lock

6. Eject (“▲”) button
7. Cassette deck compartment
8. Auxiliary audio input jack


1. Rear speaker (× 2)
2. Passenger volume control knob
3. Passenger headset jack

## **WARNING**


- It is dangerous to operate the audio system controls while riding. Never take your hands off the handlebars while riding.
- Keep the volume at a low enough level to be aware of traffic conditions and ensure safety.

## **CAUTION:**

- Do not use the audio system for a long period of time when the engine is not running as the battery may discharge.
- The control unit, cassette deck and speakers are water-resistant; however, it is good practice to cover them with a plastic bag when washing the motorcycle.
- When cleaning the control unit display, use a neutral detergent. Never use strong abrasive cleaning products, fuel (gasoline), thinner, etc.



1. Rider headset jack




1. Passenger headset jack

## **Headsets (optional)**

For intercom use, two headsets are necessary. Consult a Yamaha dealer if you wish to obtain headsets.

Connect the headsets to the jacks shown in the illustrations and make sure that the headsets are selected as the output. (See the “Selecting the output” section on page 4-6 for further instructions.)

# AUDIO SYSTEM



1. Volume control knob
2. Up/down (“”) switch
3. Audio system button “AUDIO”
4. Selection button “SELECT”

## Control unit

### Volume control knob

This knob adjusts the audio system volume.

### Up/down (“”) switch

This switch is used to perform the following operations.

### Short push (less than one second)

- Skipping songs on the cassette tape
- Selecting a preset radio station
- Selecting a track on the optional CD changer
- Tuning in a radio station manually
- Adjusting the intercom volume
- Changing the settings in a mode

### Long push (one second or more)


- Changing the cassette deck play direction
- Tuning in a radio station automatically
- Selecting a CD in the optional CD changer

### **Audio system button “AUDIO”**

This button is used to perform the following operations.

### Short push (less than one second)

- Turning on the audio system
- Changing the audio source in the following sequence



\* The CD mode appears in the display only when the optional CD changer is installed.

### Long push (one second or more)


- Turning off the audio system

## Selection button “SELECT”

This button is used to perform the following operations.

### Short push (less than two seconds)

- Changing modes in the following sequence



<sup>1</sup> This mode does not appear in the display when the headsets are selected as the output.



<sup>2</sup> This mode appears in the display only when one of the radio frequency bands is selected as the audio source.

- Programming preset radio stations

### Long push (two seconds or more)

- Selecting the preset radio station programming mode

# AUDIO SYSTEM



## Making mode settings

### General procedure

The following setting procedure applies to the audio system and optional CD changer.

### NOTE: \_\_\_\_\_

In order to make settings in any of the audio system modes, make sure that the audio system is selected. If necessary, push the “AUDIO” button for less than one second.

1. Push the “AUDIO” button for less than one second.
2. Repeatedly push the “SELECT” button for less than one second until the desired mode appears in the display. With each press of the button, the mode changes in the following sequence.

4

## Making basic settings

### Turning on/off the audio system

To turn the power on


1. Make sure that the key is in the “ACC” or “ON” position.
2. Push the “AUDIO” button once for less than one second.

To turn the power off

Push the “AUDIO” button once for one second or more.

### Adjusting the audio system volume


Turn the volume control knob until the desired audio system volume is displayed (e.g., “Vo:10”). The audio system volume can be set between “0” and “30”. After the adjustment is made, the audio system returns to normal operation and the current audio mode appears in the display.



<sup>1</sup> This mode does not appear in the display when the headsets are selected as the output.

<sup>2</sup> This mode appears in the display only when one of the radio frequency bands is selected as the audio source.

3. While the selected mode is displayed (for about five seconds), repeatedly push either side of the up/down switch for less than one second until the desired setting is displayed.




### Selecting the output (speakers or headsets)

1. Repeatedly push the "SELECT" button for less than one second until either "SP" (speakers) or "HS" and "🎧" (headsets) appear in the display.
2. Push either side of the up/down switch for less than one second to change the setting.

### NOTE:



The speakers and headsets cannot be used at the same time.



### Adjusting the bass level

1. Repeatedly push the "SELECT" button for less than one second until "BASS" appears at the bottom of the display.
2. Repeatedly push either side of the up/down switch for less than one second until the desired level is displayed. The bass level can be set between "-6" and "+6".

# AUDIO SYSTEM



set between "F9" (front speakers only) and "R9" (rear speakers only).

**NOTE:** \_\_\_\_\_  
When the fade level is set to "0", the front and rear speaker levels are the same.  
\_\_\_\_\_

4



## Adjusting the treble level

1. Repeatedly push the "SELECT" button for less than one second until "TREB" appears at the bottom of the display.
2. Repeatedly push either side of the up/down switch for less than one second until the desired level is displayed. The treble level can be set between "-6" and "+6".

## Adjusting the fade level (balance between front and rear speakers)

1. Make sure that the speakers are selected as the output source. (See the "Selecting the output" section on page 4-6 for selection procedures.)
2. Repeatedly push the "SELECT" button for less than one second until "FAD" appears at the bottom of the display.
3. Repeatedly push either side of the up/down switch for less than one second until the desired level is displayed. The fade level can be





## Intercom operation

Provided both the rider and passenger are wearing headsets, they can talk to each other through the intercom at any time.

### Adjusting the intercom volume


1. Repeatedly push the "SELECT" button for less than one second until the intercom volume (e.g., "IC:10") appears in the display.
2. Repeatedly push either side of the up/down switch for less than one second until the desired volume is displayed. The intercom volume can be set between "0" and "20".

### Adjusting the auto volume


When riding the motorcycle, external noise may override the audio system output volume. The audio system features an automatic volume control function which compensates for external noise.

1. Repeatedly push the "SELECT" button for less than one second until the auto volume (e.g., "AV: 3") appears in the display.
2. Repeatedly push either side of the up/down switch for less than one second until the desired volume is displayed. The auto volume can be set between "0" and "5".

# AUDIO SYSTEM



1. Cassette deck compartment
2. Eject ("▲") button
3. Cassette deck lid



- To clean the tape head, use a de-magnetizing cleaning cassette, but be sure to turn the volume all the way down to avoid speaker damage.

4



## Cassette deck operation

### **⚠ WARNING**

- It is dangerous to operate the cassette deck while riding. Never take your hands off the handlebars while riding.
- Keep the volume at a low enough level to be aware of traffic conditions and ensure safety.

### **CAUTION:**

- Keep the cassette deck lid closed at all times, except when inserting or removing a cassette.
- Do not leave cassette tapes in direct sunlight for a long period of time.
- Do not allow the inside of the cassette deck to get wet. If this happens, keep the cassette deck lid open and dry out the deck in the shade.



**NOTE:** \_\_\_\_\_

- The maximum number of songs that can be skipped in either direction is 9.
- To stop skipping songs, push the up/down switch in the opposite direction that songs are being skipped.




## Playing a cassette tape

1. Make sure that the audio system is turned on. (See page 4-3.)
2. Insert a cassette tape into the cassette compartment as shown. "LOAD", then "PLAY" appears in the display. (If a cassette is already inserted, push the "AUDIO" button until "PLAY" appears in the display.) The tape starts playing.

## Skipping songs

While a cassette tape is playing, push either side of the up/down switch once for less than one second for each song to be skipped. Pushing "▽" skips songs in the forward direction. Pushing "△" skips songs in the reverse direction. "APC" (auto program control) and the number of songs to be skipped (e.g., "3") appear in the display. When skipping songs in reverse, a minus sign appears in front of the number of songs to be skipped (e.g., "-2"). ("-1" indicates that the current song will be played again.)

# AUDIO SYSTEM



4

## Skipping a blank

When there is a long blank portion of tape on the cassette, "BLS" appears in the display and the cassette deck automatically fast-forwards the tape to the next song.

## Changing the tape play direction


While the cassette tape is playing, push either side of the up/down switch for more than one second to reverse the play direction. "F" appears in the display when the tape is played in the forward direction. "R" appears in the display when the tape is played in the reverse direction.

## Turning on/off the Dolby noise reduction system

While the cassette tape is playing, push the eject ("▲") button for more than two seconds to turn the Dolby B noise reduction system on or off. "B NR" appears in the display when the noise reduction system is turned on.

## NOTE:


- The Dolby noise reduction system has been manufactured under license from Dolby Laboratories Licensing Corporation.
- Dolby and the double “D” symbol are registered trademarks of Dolby Laboratories Licensing Corporation.



1. Eject (“▲”) button

### Ejecting the cassette tape

Push the eject (“▲”) button to eject the tape from the cassette deck. “EJCT” appears in the display, and then “CASS” starts flashing.




1. Radio antenna

### Radio operation


#### **WARNING**

- It is dangerous to operate the radio while riding. Never take your hands off the handlebars while riding.
- Keep the volume at a low enough level to be aware of traffic conditions and ensure safety.
- Never ride the motorcycle with the radio antenna folded down.


# AUDIO SYSTEM



1. Antenna sleeve



1. Frequency band




## NOTE:

- Lift the sleeve to fold the antenna down.
- Be sure to lower the sleeve fully after putting the antenna back to the original position.

## Selecting a frequency band


This radio offers three FM bands and one AM band. Since all three FM bands cover the whole FM frequency range, any one of them can be selected for tuning in an FM station. These three FM bands are useful for categorizing FM preset stations. Repeatedly push the “AUDIO” button for less than one second until the desired frequency band appears in the display.



\* The CD mode appears in the display only when the optional CD changer is installed.

## Tuning in a radio station automatically

1. Select a frequency band.
2. Push either side of the up/down switch once for one second or more. The radio automatically tunes in the first station that has a strong enough signal to be received.




3. Push either side of the up/down switch for less than one second until the desired frequency is displayed. The frequency changes in 0.2-MHz steps for FM and in 10-kHz steps for AM.

## Tuning in a radio station manually

In order to tune in a particular radio station (e.g., when the signal is too weak for automatic tuning), the radio frequency can be selected manually as follows.

1. Select a frequency band. (See page 4-13.)
2. Repeatedly push the "SELECT" button for less than one second until the currently selected radio frequency appears in the display.




1. Preset station number

## Tuning in a preset radio station

1. Select a frequency band. (See page 4-13.)
2. Repeatedly push either side of the up/down switch for less than one second until the desired preset station number is displayed.

**NOTE:** \_\_\_\_\_  
To be able to tune in a preset radio station, you must have previously programmed at least one. (See the following sections.)

# AUDIO SYSTEM



4

## Programming preset radio stations manually

Up to six stations can be programmed for each frequency band (FM1, FM2, FM3, and AM) using either manual or automatic tuning.

### Using manual tuning

1. Manually tune in a radio station that you wish to preset. (See page 4-14.)
2. Push the “SELECT” button once for two seconds or more. The radio frequency and preset station number “1” (to the right of “CH.”) start flashing.

3. Repeatedly push either side of the up/down switch for less than one second until the desired preset number (“1” through “6”) is displayed.

### **NOTE:**



Selecting “A” will automatically program the preset stations. See the following section.

4. Push the “SELECT” button once for less than one second to store the radio station selected in step 1 under the preset number selected in step 3.
5. Repeat this procedure to preset other radio stations.

### Using automatic tuning

1. Select a frequency band. (See page 4-13.)
2. Push the “SELECT” button once for two seconds or more. The radio frequency and preset station number “1” (to the right of “CH.”) start flashing.
3. Push either side of the up/down switch once for one second or more to tune in a station automatically.
4. Repeatedly push either side of the up/down switch for less than one second until the desired preset number (“1” through “6”) is displayed.
5. Push the “SELECT” button once for less than one second to store the radio station selected in step 3 under the preset number selected in step 4.
6. Repeat this procedure to preset other radio stations.





## Programming preset radio stations automatically

Up to six stations can be programmed automatically for each frequency band (FM1, FM2, FM3, and AM) as follows.

**NOTE:** \_\_\_\_\_  
This function works best in areas with strong radio signals.

1. Select a frequency band. (See page 4-13.)
2. Push the “SELECT” button once for two seconds or more. The radio frequency and preset station number “1” (to the right of “CH.”) start flashing.
3. Repeatedly push either side of the up/down switch for less than one second until “A” (automatic) appears in the display.
4. Push the “SELECT” button once for less than one second to program preset radio stations automatically.



# AUDIO SYSTEM

## Optional CD changer operation

### **WARNING**

- It is dangerous to operate the CD changer while riding. Never take your hands off the handlebars while riding.
- Keep the volume at a low enough level to be aware of traffic conditions and ensure safety.

An optional six-disc CD changer can be mounted in the travel trunk. Ask a Yamaha dealer to install the genuine Clarion CDC635 model.



### Playing a CD

1. Insert up to six CDs into the CD changer. Follow the manufacturer's directions.
2. Push the "AUDIO" button until "Ⓢ" as well as the CD number and track number (e.g., "6-3") appear in the display. The CD starts playing.

### NOTE:


"6-3" indicates track no. 3 on CD no. 6.

### Selecting a CD

Repeatedly push either side of the up/down switch for one second or more until the number for the desired CD appears in the display.

### Selecting a CD track

Repeatedly push either side of the up/down switch for less than one second until the number for the desired CD track appears in the display.




1. Auxiliary audio input jack

## Auxiliary audio source operation

Auxiliary audio equipment can be connected to, and played through, the audio system.

1. Insert the output plug of the auxiliary equipment into the jack located at the right of the cassette deck.



2. Repeatedly push the “AUDIO” button for less than one second until “AUX” appears in the display. The auxiliary equipment can now be played through the audio system.



Pre-operation check list ..... 5-1

# **PRE-OPERATION CHECKS**

The condition of a vehicle is the owner's responsibility. Vital components can start to deteriorate quickly and unexpectedly, even if the vehicle remains unused (for example, as a result of exposure to the elements). Any damage, fluid leakage or loss of tire air pressure could have serious consequences. Therefore, it is very important, in addition to a thorough visual inspection, to check the following points before each ride.

## **Pre-operation check list**

<b>ITEM</b>	<b>CHECKS</b>	<b>PAGE</b>
<b>Fuel</b>	<ul style="list-style-type: none"><li>• Check fuel level in fuel tank.</li><li>• Refuel if necessary.</li><li>• Check fuel line for leakage.</li></ul>	3-12
<b>Engine oil</b>	<ul style="list-style-type: none"><li>• Check oil level in engine.</li><li>• If necessary, add recommended oil to specified level.</li><li>• Check vehicle for oil leakage.</li></ul>	7-12
<b>Final gear oil</b>	<ul style="list-style-type: none"><li>• Check vehicle for oil leakage.</li></ul>	7-15
<b>Coolant</b>	<ul style="list-style-type: none"><li>• Check coolant level in reservoir.</li><li>• If necessary, add recommended coolant to specified level.</li><li>• Check cooling system for leakage.</li></ul>	7-15–7-16
<b>Front brake</b>	<ul style="list-style-type: none"><li>• Check operation.</li><li>• If soft or spongy, have Yamaha dealer bleed hydraulic system.</li><li>• Check lever free play.</li><li>• Adjust if necessary.</li><li>• Check fluid level in reservoir.</li><li>• If necessary, add recommended brake fluid to specified level.</li><li>• Check hydraulic system for leakage.</li></ul>	7-25, 7-27–7-29
<b>Rear brake</b>	<ul style="list-style-type: none"><li>• Check operation.</li><li>• If soft or spongy, have Yamaha dealer bleed hydraulic system.</li><li>• Check fluid level in reservoir.</li><li>• If necessary, add recommended brake fluid to specified level.</li><li>• Check hydraulic system for leakage.</li></ul>	7-26–7-29

# PRE-OPERATION CHECKS

ITEM	CHECKS	PAGE
<b>Clutch</b>	<ul style="list-style-type: none"> <li>• Check operation.</li> <li>• If soft or spongy, have Yamaha dealer bleed hydraulic system.</li> <li>• Check fluid level in reservoir.</li> <li>• If necessary, add recommended fluid to specified level.</li> <li>• Check hydraulic system for leakage.</li> </ul>	7-25, 7-28
<b>Throttle grip</b>	<ul style="list-style-type: none"> <li>• Make sure that operation is smooth.</li> <li>• Lubricate throttle grip, housing and cables if necessary.</li> <li>• Check free play.</li> <li>• If necessary, have Yamaha dealer make adjustment.</li> </ul>	7-21
<b>Control cables</b>	<ul style="list-style-type: none"> <li>• Make sure that operation is smooth.</li> <li>• Lubricate if necessary.</li> </ul>	—
<b>Wheels and tires</b>	<ul style="list-style-type: none"> <li>• Check for damage.</li> <li>• Check tire condition and tread depth.</li> <li>• Check air pressure.</li> <li>• Correct if necessary.</li> </ul>	7-21–7-24
<b>Brake and shift pedals</b>	<ul style="list-style-type: none"> <li>• Make sure that operation is smooth.</li> <li>• Lubricate pedal pivoting points if necessary.</li> </ul>	7-29
<b>Brake and clutch levers</b>	<ul style="list-style-type: none"> <li>• Make sure that operation is smooth.</li> <li>• Lubricate lever pivoting points if necessary.</li> </ul>	7-30
<b>Sidestand</b>	<ul style="list-style-type: none"> <li>• Make sure that operation is smooth.</li> <li>• Lubricate pivot if necessary.</li> </ul>	7-30
<b>Chassis fasteners</b>	<ul style="list-style-type: none"> <li>• Make sure that all nuts, bolts and screws are properly tightened.</li> <li>• Tighten if necessary.</li> </ul>	—
<b>Instruments, lights, signals and switches</b>	<ul style="list-style-type: none"> <li>• Check operation.</li> <li>• Correct if necessary.</li> </ul>	—
<b>Sidestand switch</b>	<ul style="list-style-type: none"> <li>• Check operation of ignition circuit cut-off system.</li> <li>• If system is defective, have Yamaha dealer check vehicle.</li> </ul>	3-21

# PRE-OPERATION CHECKS

---

---

**NOTE:**

Pre-operation checks should be made each time the motorcycle is used. Such an inspection can be accomplished in a very short time; and the added safety it assures is more than worth the time involved.

---

** WARNING**

**If any item in the Pre-operation check list is not working properly, have it inspected and repaired before operating the motorcycle.**

---





# OPERATION AND IMPORTANT RIDING POINTS

---

Starting the engine .....	6-1
Starting a warm engine .....	6-3
Shifting .....	6-3
Recommended shift points (for Switzerland only) .....	6-4
Tips for reducing fuel consumption .....	6-4
Engine break-in .....	6-5
Parking .....	6-6

# OPERATION AND IMPORTANT RIDING POINTS

---



## **! WARNING**

- Become thoroughly familiar with all operating controls and their functions before riding. Consult a Yamaha dealer regarding any control or function that you do not thoroughly understand.
- Never start the engine or operate it in a closed area for any length of time. Exhaust fumes are poisonous, and inhaling them can cause loss of consciousness and death within a short time. Always make sure that there is adequate ventilation.

- Before starting out, make sure that the sidestand is up. If the sidestand is not raised completely, it could contact the ground and distract the operator, resulting in a possible loss of control.

## **Starting the engine**


In order for the ignition circuit cut-off system to enable starting, one of the following conditions must be met:

- The transmission is in the neutral position.
- The transmission is in gear with the clutch lever pulled and the sidestand up.

## **! WARNING**

- Before starting the engine, check the function of the ignition circuit cut-off system according to the procedure described on page 3-23.
- Never ride with the sidestand down.

# OPERATION AND IMPORTANT RIDING POINTS



1. Turn the fuel cock lever to "ON".
2. Turn the key to "ON" and make sure that the engine stop switch is set to "O".


## CAUTION:

**If the fuel level warning light comes on, check the fuel level, and, if necessary, refuel as soon as possible.**

3. Shift the transmission into the neutral position.

## NOTE:

When the transmission is in the neutral position, the neutral indicator light should be on, otherwise have a Yamaha dealer check the electrical circuit.



4. Turn the starter (choke) on and completely close the throttle. (See page 3-14 for starter (choke) operation.)
5. Start the engine by pushing the start switch.

## NOTE:

If the engine fails to start, release the start switch, wait a few seconds, and then try again. Each starting attempt should be as short as possible to preserve the battery. Do not crank the engine more than 10 seconds on any one attempt.

# OPERATION AND IMPORTANT RIDING POINTS

## CAUTION:

The engine trouble warning light should come on when the start switch is pushed, and it should go off when the start switch is released. If the engine trouble warning does not come on when pushing the start switch, or it remains on after starting, have a Yamaha dealer check the self-diagnosis device.

6. After starting the engine, move the starter (choke) knob back halfway.

## CAUTION:

For maximum engine life, never accelerate hard when the engine is cold!


7. When the engine is warm, turn the starter (choke) off.

## NOTE:

The engine is warm when it responds normally to the throttle with the starter (choke) turned off.

## Starting a warm engine

Follow the same procedure as for starting a cold engine with the exception that the starter (choke) is not required when the engine is warm.



## Shifting

Shifting gears lets you control the amount of engine power available for starting off, accelerating, climbing hills, etc.

The gear positions are shown in the illustration.

## NOTE:

To shift the transmission into the neutral position, press the shift pedal down repeatedly until it reaches the end of its travel, and then slightly raise it.

# OPERATION AND IMPORTANT RIDING POINTS

## CAUTION:

- Even with the transmission in the neutral position, do not coast for long periods of time with the engine off, and do not tow the motorcycle for long distances. The transmission is properly lubricated only when the engine is running. Inadequate lubrication may damage the transmission.
- Always use the clutch while changing gears to avoid damaging the engine, transmission, and drive train, which are not designed to withstand the shock of forced shifting.

## Recommended shift points (for Switzerland only)

The recommended shift points during acceleration are shown in the table below.

	Shift point (km/h)
1st → 2nd	23
2nd → 3rd	36
3rd → 4th	50
4th → 5th	60

## NOTE:

When shifting down two gears at a time, reduce the speed accordingly (e.g., down to 35 km/h when shifting from 4th to 2nd gear).

## Tips for reducing fuel consumption

Fuel consumption depends largely on your riding style. Consider the following tips to reduce fuel consumption:

- Thoroughly warm up the engine.
- Turn the starter (choke) off as soon as possible.
- Shift up swiftly, and avoid high engine speeds during acceleration.
- Do not rev the engine while shifting down, and avoid high engine speeds with no load on the engine.
- Turn the engine off instead of letting it idle for an extended length of time (e.g., in traffic jams, at traffic lights or at railroad crossings).


# OPERATION AND IMPORTANT RIDING POINTS

---

## Engine break-in

There is never a more important period in the life of your engine than the period between 0 and 1,600 km. For this reason, you should read the following material carefully.

Since the engine is brand new, do not put an excessive load on it for the first 1,600 km. The various parts in the engine wear and polish themselves to the correct operating clearances. During this period, prolonged full-throttle operation or any condition that might result in engine overheating must be avoided.



### 0–1,000 km

Avoid prolonged operation above 1/3 throttle.

### 1,000–1,600 km

Avoid prolonged operation above 1/2 throttle.

### CAUTION:

After 1,000 km of operation, the engine oil and final gear oil must be changed, and the oil filter cartridge replaced.

---


### 1,600 km and beyond

The vehicle can now be operated normally.

### CAUTION:

If any engine trouble should occur during the engine break-in period, immediately have a Yamaha dealer check the vehicle.

---



## Parking

When parking, stop the engine, remove the key from the main switch, and then turn the fuel cock lever to “OFF”.

### **WARNING**

- Since the engine and exhaust system can become very hot, park in a place where pedestrians or children are not likely to touch them.
- Do not park on a slope or on soft ground, otherwise the motorcycle may overturn.





# PERIODIC MAINTENANCE AND MINOR REPAIR

Owner's tool kit .....	7-1	Checking the front and rear brake pads .....	7-27
Periodic maintenance and lubrication chart .....	7-3	Checking the brake and clutch fluid levels .....	7-28
Removing and installing cowlings and panels .....	7-6	Changing the brake and clutch fluids .....	7-29
Checking the spark plugs .....	7-11	Checking and lubricating the brake and shift pedals .....	7-29
Engine oil and oil filter cartridge .....	7-12	Checking and lubricating the brake and clutch levers .....	7-30
Final gear oil .....	7-15	Checking and lubricating the sidestand .....	7-30
Checking the coolant level .....	7-15	Checking the front fork .....	7-31
Cleaning the air filter elements .....	7-17	Checking the steering .....	7-31
Adjusting the carburetors .....	7-19	Battery .....	7-32
Adjusting the engine idling speed .....	7-20	Replacing the fuses .....	7-33
Adjusting the throttle cable free play .....	7-21	Replacing the headlight bulb .....	7-35
Adjusting the valve clearance .....	7-21	Replacing a turn signal light bulb or the tail/brake light bulb .....	7-36
Tires .....	7-21	Replacing the license plate light bulb .....	7-37
Cast wheels .....	7-24	Troubleshooting .....	7-37
Clutch lever free play .....	7-25	Troubleshooting charts .....	7-38
Adjusting the brake lever free play .....	7-25		
Adjusting the brake pedal position .....	7-26		
Adjusting the rear brake light switch .....	7-26		


# PERIODIC MAINTENANCE AND MINOR REPAIR



VALS MAY NEED TO BE SHORTENED.

## **⚠ WARNING**

**If you are not familiar with motorcycle maintenance work, have a Yamaha dealer do it for you.**



1. Owner's tool kit

Safety is an obligation of the owner. Periodic inspection, adjustment and lubrication will keep your vehicle in the safest and most efficient condition possible. The most important points of inspection, adjustment, and lubrication are explained on the following pages.

The intervals given in the periodic maintenance and lubrication chart should be simply considered as a general guide under normal riding conditions. However, DEPENDING ON THE WEATHER, TERRAIN, GEOGRAPHICAL LOCATION, AND INDIVIDUAL USE, THE MAINTENANCE INTER-

## **Owner's tool kit**

The owner's tool kit is located inside the right side case. (See page 3-17 for side case opening procedures.)

The service information included in this manual and the tools provided in the owner's tool kit are intended to assist you in the performance of preventive maintenance and minor repairs. However, additional tools such as a torque wrench may be necessary to perform certain maintenance work correctly.

# PERIODIC MAINTENANCE AND MINOR REPAIR

---

---

## NOTE:

If you do not have the tools or experience required for a particular job, have a Yamaha dealer perform it for you.

## WARNING

Modifications not approved by Yamaha may cause loss of performance and render the vehicle unsafe for use. Consult a Yamaha dealer before attempting any changes.

# PERIODIC MAINTENANCE AND MINOR REPAIR

## Periodic maintenance and lubrication chart

### NOTE:

- The annual checks must be performed every year, except if a kilometer-based maintenance is performed instead.
- From 50,000 km, repeat the maintenance intervals starting from 10,000 km.
- Items marked with an asterisk should be performed by a Yamaha dealer as they require special tools, data and technical skills.

NO.	ITEM	CHECK OR MAINTENANCE JOB	ODOMETER READING (× 1,000 km)					ANNUAL CHECK
			1	10	20	30	40	
1	* Fuel line	• Check fuel hoses for cracks or damage.		√	√	√	√	√
2	* Fuel filter	• Check condition.			√		√	
3	Spark plugs	• Check condition. • Clean and regap.		√		√		
		• Replace.			√		√	
4	* Valves	• Check valve clearance. • Adjust.	Every 40,000 km					
5	Air filter element	• Clean.		√		√		
		• Replace.			√		√	
6	* Clutch	• Check operation, fluid level and vehicle for fluid leakage. (See NOTE on page 7-5.)	√	√	√	√	√	
7	* Front brake	• Check operation, fluid level and vehicle for fluid leakage. (See NOTE on page 7-5.)	√	√	√	√	√	√
		• Replace brake pads.	Whenever worn to the limit					
8	* Rear brake	• Check operation, fluid level and vehicle for fluid leakage. (See NOTE on page 7-5.)	√	√	√	√	√	√
		• Replace brake pads.	Whenever worn to the limit					
9	* Brake hoses	• Check for cracks or damage.		√	√	√	√	√
		• Replace. (See NOTE on page 7-5.)	Every 4 years					

# PERIODIC MAINTENANCE AND MINOR REPAIR

NO.	ITEM	CHECK OR MAINTENANCE JOB	ODOMETER READING (× 1,000 km)					ANNUAL CHECK
			1	10	20	30	40	
10	* <b>Wheels</b>	• Check runout and for damage.		√	√	√	√	
11	* <b>Tires</b>	• Check tread depth and for damage. • Replace if necessary. • Check air pressure. • Correct if necessary.		√	√	√	√	
12	* <b>Wheel bearings</b>	• Check bearing for looseness or damage.		√	√	√	√	
13	* <b>Swingarm</b>	• Check operation and for excessive play.		√	√	√	√	
		• Lubricate with lithium-soap-based grease.	Every 50,000 km					
14	* <b>Steering bearings</b>	• Check bearing play and steering for roughness.	√	√	√	√	√	
		• Lubricate with lithium-soap-based grease.	Every 50,000 km					
15	* <b>Chassis fasteners</b>	• Make sure that all nuts, bolts and screws are properly tightened.		√	√	√	√	√
16	<b>Sidestand</b>	• Check operation. • Lubricate.		√	√	√	√	√
17	* <b>Sidestand switch</b>	• Check operation.	√	√	√	√	√	√
18	* <b>Front fork</b>	• Check operation and for oil leakage.		√	√	√	√	
19	* <b>Shock absorber assembly</b>	• Check operation and shock absorber for oil leakage.		√	√	√	√	
20	* <b>Rear suspension relay arm and connecting arm pivoting points</b>	• Check operation.		√	√	√	√	
		• Lubricate with lithium-soap-based grease.			√		√	
21	* <b>Carburetors</b>	• Check starter (choke) operation. • Adjust engine idling speed and synchronization.	√	√	√	√	√	√
22	<b>Engine oil</b>	• Change.	√	√	√	√	√	√
23	<b>Engine oil filter cartridge</b>	• Replace.	√		√		√	
24	* <b>Cooling system</b>	• Check coolant level and vehicle for coolant leakage.		√	√	√	√	√
		• Change.	Every 3 years					


# PERIODIC MAINTENANCE AND MINOR REPAIR

NO.	ITEM	CHECK OR MAINTENANCE JOB	ODOMETER READING (× 1,000 km)					ANNUAL CHECK
			1	10	20	30	40	
25	Final gear oil	• Check oil level and vehicle for oil leakage.	√	√		√		
		• Change.	√		√		√	
26	* Front and rear brake switches	• Check operation.	√	√	√	√	√	√
27	Moving parts and cables	• Lubricate.		√	√	√	√	√
28	* Lights, signals and switches	• Check operation. • Adjust headlight beam.	√	√	√	√	√	√


**NOTE:** \_\_\_\_\_

- The air filter needs more frequent service if you are riding in unusually wet or dusty areas.
- Hydraulic brake and clutch systems
  - After disassembling the brake or clutch master cylinders, caliper cylinders or clutch release cylinder, always change the fluid. Regularly check the brake and clutch fluid levels and fill the reservoirs as required.
  - Replace the oil seals on the inner parts of the brake or clutch master cylinders, caliper cylinders and clutch release cylinder every two years.
  - Replace the brake and clutch hoses every four years or if cracked or damaged.


# PERIODIC MAINTENANCE AND MINOR REPAIR



1. Cowling A
2. Panel A



1. Cowling B
2. Panel B
3. Panel C



1. Cowling A
2. Screw (× 2)
3. Quick fastener

## Removing and installing cowlings and panels

The cowlings and panels shown above need to be removed to perform some of the maintenance jobs described in this chapter. Refer to this section each time a cowling or panel needs to be removed and installed.

### Cowling A

To remove the cowling

Remove the screws and the quick fastener, and then pull the cowling off as shown.


### NOTE:

The quick fastener is removed by pushing the center pin in with a screwdriver, then pulling the fastener out.

# PERIODIC MAINTENANCE AND MINOR REPAIR




1. Screw



1. Grommet
2. Projection
3. Cowling A

## To install the cowling

Place the cowling in the original position, and then install the screws and the quick fastener.




## **NOTE:**

- Make sure that the projection fits into the grommet.
- To install the quick fastener, push the center pin out so that it will protrude from the fastener head, insert the fastener into the cowling, and then push the protruding pin in until it is flush with the fastener head.



# PERIODIC MAINTENANCE AND MINOR REPAIR




1. Cowling B
2. Screw (× 2)

## Cowling B

### To remove the cowling

1. Remove cowling A.
2. Remove the screws, and then pull the cowling off as shown.



1. Screw

### To install the cowling


1. Place the cowling in the original position, and then install the screws.

### **NOTE:** \_\_\_\_\_

Make sure that the projection fits into the grommet.

2. Install cowling A.

# PERIODIC MAINTENANCE AND MINOR REPAIR




1. Panel A
2. Screw

## **Panel A**


### To remove the panel

Remove the screw, and then pull the panel off as shown.



### To install the panel

Place the panel in the original position, and then install the screw.




1. Panel B
2. Screw

## **Panel B**

### To remove the panel


Remove the screw, and then pull the panel off as shown.

# PERIODIC MAINTENANCE AND MINOR REPAIR



## To install the panel

Place the panel in the original position, and then install the screw.




1. Panel C
2. Screw
3. Bolt (× 2)

## **Panel C**

### To remove the panel

1. Remove the left passenger footrest by removing the bolts.
2. Remove the screw, and then pull the panel off as shown.



## To install the panel


1. Place the panel in the original position, and then install the screw.
2. Install the passenger footrest by installing the bolts.

# PERIODIC MAINTENANCE AND MINOR REPAIR

## Checking the spark plugs

The spark plugs are important engine components, which should be checked periodically, preferably by a Yamaha dealer. Since heat and deposits will cause any spark plug to slowly erode, they should be removed and checked in accordance with the periodic maintenance and lubrication chart. In addition, the condition of the spark plugs can reveal the condition of the engine.

The porcelain insulator around the center electrode of each spark plug should be a medium-to-light tan (the ideal color when the motorcycle is ridden normally), and all spark plugs installed in the engine should have the same color. If any spark plug shows a distinctly different color, the engine could be defective. Do not attempt to diagnose such problems yourself. Instead, have a Yamaha dealer check the motorcycle. If a spark plug shows signs of electrode erosion and excessive carbon or other deposits, it should be replaced.



a. Spark plug gap

Specified spark plug:  
DPR8EA-9 (NGK) or  
X24EPR-U9 (DENSO)

Before installing a spark plug, the spark plug gap should be measured with a wire thickness gauge and, if necessary, adjusted to specification.

Spark plug gap:  
0.8–0.9 mm

Clean the surface of the spark plug gasket and its mating surface, and then wipe off any grime from the spark plug threads.

Tightening torque:  
Spark plug:  
17.5 Nm (1.75 m·kgf)

**NOTE:** If a torque wrench is not available when installing a spark plug, a good estimate of the correct torque is 1/4–1/2 turn past finger tight. However, the spark plug should be tightened to the specified torque as soon as possible.

# PERIODIC MAINTENANCE AND MINOR REPAIR

## Engine oil and oil filter cartridge


The engine oil level should be checked before each ride. In addition, the oil must be changed and the oil filter cartridge replaced at the intervals specified in the periodic maintenance and lubrication chart.

### To check the engine oil level

1. Place the motorcycle on a level surface and hold it in an upright position.

**NOTE:** \_\_\_\_\_  
Make sure that the motorcycle is positioned straight up when checking the oil level. A slight tilt to the side can result in a false reading.


2. Start the engine, warm it up for several minutes, and then turn it off.



1. Engine oil level check window
  2. Maximum level mark
  3. Minimum level mark
3. Wait a few minutes until the oil settles, and then check the oil level through the check window located at the bottom-right side of the crankcase.

**NOTE:** \_\_\_\_\_  
The engine oil should be between the minimum and maximum level marks.

4. If the engine oil is below the minimum level mark, add sufficient oil of the recommended type to raise it to the correct level.




1. Engine oil filler cap

### To change the engine oil (with or without oil filter cartridge replacement)

1. Start the engine, warm it up for several minutes, and then turn it off.
2. Place an oil pan under the engine to collect the used oil.

# PERIODIC MAINTENANCE AND MINOR REPAIR



1. Engine oil drain bolt

3. Remove the engine oil filler cap and drain bolt to drain the oil from the crankcase.

**NOTE:** \_\_\_\_\_  
Skip steps 4–6 if the oil filter cartridge is not being replaced.




1. Engine oil filter cartridge

4. Remove the oil filter cartridge with an oil filter wrench.

**NOTE:** \_\_\_\_\_  
An oil filter wrench is available at a Yamaha dealer.

5. Apply a thin coat of engine oil to the O-ring of the new oil filter cartridge.

**NOTE:** \_\_\_\_\_  
Make sure that the O-ring is properly seated.



1. Torque wrench  
2. Oil filter wrench

6. Install the new oil filter cartridge, and then tighten it to the specified torque with a torque wrench.

Tightening torque:  
Oil filter cartridge:  
17 Nm (1.7 m·kgf)

7. Install the engine oil drain bolt, and then tighten it to the specified torque.

Tightening torque:  
Engine oil drain bolt:  
43 Nm (4.3 m·kgf)

# PERIODIC MAINTENANCE AND MINOR REPAIR

8. Add the specified amount of the recommended engine oil, and then install and tighten the oil filler cap.

Recommended engine oil:

See page 9-1.

Oil quantity:

Without oil filter cartridge  
replacement:

3.5 L

With oil filter cartridge  
replacement:

3.7 L

Total amount (dry engine):

4.3 L

**CAUTION:** \_\_\_\_\_

- In order to prevent clutch slippage (since the engine oil also lubricates the clutch), do not mix any chemical additives with the oil or use oils of a higher grade than “CD”. In addition, do not use oils labeled “ENERGY CONSERVING II” or higher.
- Make sure that no foreign material enters the crankcase.

9. Start the engine, and then let it idle for several minutes while checking it for oil leakage. If oil is leaking, immediately turn the engine off and check for the cause.

**NOTE:** \_\_\_\_\_


After the engine is started, the engine oil level warning light should go off if the oil level is sufficient.

**CAUTION:** \_\_\_\_\_

If the oil level warning light flickers or remains on, immediately turn the engine off and have a Yamaha dealer check the vehicle.

10. Turn the engine off, and then check the oil level and correct it if necessary.

# PERIODIC MAINTENANCE AND MINOR REPAIR



1. Final gear oil filler bolt
2. Final gear oil drain bolt

## Final gear oil

The final gear case must be checked for oil leakage before each ride. If any leakage is found, have a Yamaha dealer check and repair the motorcycle. In addition, have a Yamaha dealer change the final gear oil at the intervals specified in the periodic maintenance and lubrication chart.


## Checking the coolant level

The coolant level should be checked as follows before each ride. In addition, the coolant must be changed at the intervals specified in the periodic maintenance and lubrication chart.

1. Place the motorcycle on a level surface and hold it in an upright position.
2. Remove panel A. (See page 7-9 for panel removal and installation procedures.)

### NOTE: \_\_\_\_\_

- The coolant level must be checked on a cold engine since the level varies with engine temperature.
- Make sure that the motorcycle is positioned straight up when checking the coolant level. A slight tilt to the side can result in a false reading.




1. Coolant reservoir
  2. Maximum level mark
  3. Minimum level mark
3. Check the coolant level in the coolant reservoir.

### NOTE: \_\_\_\_\_

The coolant should be between the minimum and maximum level marks.



# PERIODIC MAINTENANCE AND MINOR REPAIR



1. Coolant reservoir cap

4. If the coolant is at or below the minimum level mark, remove the rider seat (See page 3-15 for rider seat removal and installation procedures.), open the reservoir cap, add coolant to the maximum level mark, and then close the reservoir cap and install the rider seat.

Coolant reservoir capacity:  
0.84 L

## CAUTION:

- If coolant is not available, use distilled water or soft tap water instead. Do not use hard water or salt water since it is harmful to the engine.
- If water has been used instead of coolant, replace it with coolant as soon as possible, otherwise the engine may not be sufficiently cooled and the cooling system will not be protected against frost and corrosion.
- If water has been added to the coolant, have a Yamaha dealer check the antifreeze content of the coolant as soon as possible, otherwise the effectiveness of the coolant will be reduced.

## ⚠ WARNING

Never attempt to remove the radiator cap when the engine is hot.

5. Install the panel.

## NOTE:

- The radiator fan is automatically switched on or off according to the coolant temperature in the radiator.
- If the engine overheats, see page 7-39 for further instructions.


# PERIODIC MAINTENANCE AND MINOR REPAIR

## Cleaning the air filter elements


The air filter elements should be cleaned at the intervals specified in the periodic maintenance and lubrication chart. Clean the air filter elements more frequently if you are riding in unusually wet or dusty areas.

1. Remove cowlings A and B. (See pages 7-6–7-8 for cowlings removal and installation procedures.)

**NOTE:** \_\_\_\_\_  
Continue as follows for each air filter element.  
\_\_\_\_\_




1. Air filter case
  2. Bolt (× 2)
2. Remove the air filter case by removing the bolts.




1. Screw
3. Loosen the air filter joint clamp screw, and then pull the air filter off.

# PERIODIC MAINTENANCE AND MINOR REPAIR



1. Bolt (× 5)


4. Remove the air filter case cover by removing the bolts.



1. Air filter element

2. Screw (× 2)

5. Remove the air filter element by removing the screws.



1. Air filter element


6. Lightly tap the air filter element to remove most of the dust and dirt, and then blow the remaining dirt out with compressed air as shown. If the air filter element is damaged, replace it.

# PERIODIC MAINTENANCE AND MINOR REPAIR

7. Install the air filter element by fitting the projection on the air filter element into the holder in the air filter case, then tightening the screws.

## CAUTION:

- Make sure that the air filter element is properly seated in the air filter case.
- The engine should never be operated without the air filter element installed, otherwise the pistons and/or cylinders may become excessively worn.



1. Air filter case drain hose
8. Install the air filter case cover by installing the bolts.
9. Install the air filter by pushing it onto the air filter joint, then tightening the air filter joint clamp screw.
10. Install the air filter case by installing the bolts.
11. Install the cowlings.

## NOTE:

Make sure that the air filter case drain hose is routed as shown.

## Adjusting the carburetors

The carburetors are important parts of the engine and require very sophisticated adjustment. Therefore, most carburetor adjustments should be left to a Yamaha dealer, who has the necessary professional knowledge and experience. The adjustment described in the following section, however, may be serviced by the owner as part of routine maintenance.

## CAUTION:

**The carburetors have been set and extensively tested at the Yamaha factory. Changing these settings without sufficient technical knowledge may result in poor performance of or damage to the engine.**


# PERIODIC MAINTENANCE AND MINOR REPAIR

## Adjusting the engine idling speed

The engine idling speed must be checked and, if necessary, adjusted as follows at the intervals specified in the periodic maintenance and lubrication chart.

**NOTE:** \_\_\_\_\_  
A diagnostic tachometer is needed to make this adjustment.

1. Attach the tachometer to the spark plug lead.



1. Throttle stop screw
2. Start the engine and warm it up for several minutes at 1,000–2,000 r/min while occasionally revving it to 4,000–5,000 r/min.


**NOTE:** \_\_\_\_\_  
The engine is warm when it quickly responds to the throttle.

3. Check the engine idling speed and, if necessary, adjust it to specification by turning the throttle stop screw. To increase the engine idling speed, turn the screw in direction ①. To decrease the engine idling speed, turn the screw in direction ②.

Engine idling speed:  
950–1,050 r/min

**NOTE:** \_\_\_\_\_  
If the specified idling speed cannot be obtained as described above, have a Yamaha dealer make the adjustment.

# PERIODIC MAINTENANCE AND MINOR REPAIR



a. Throttle cable free play

## Adjusting the throttle cable free play

The throttle cable free play should measure 4–6 mm at the throttle grip. Periodically check the throttle cable free play and, if necessary, have a Yamaha dealer adjust it.

## Adjusting the valve clearance

The valve clearance changes with use, resulting in improper air-fuel mixture and/or engine noise. To prevent this from occurring, the valve clearance must be adjusted by a Yamaha dealer at the intervals specified in the periodic maintenance and lubrication chart.



## Tires

To maximize the performance, durability, and safe operation of your motorcycle, note the following points regarding the specified tires.

### Tire air pressure

The tire air pressure should be checked and, if necessary, adjusted before each ride.

# PERIODIC MAINTENANCE AND MINOR REPAIR

## ⚠ WARNING

Tire inflation pressure should be checked and adjusted when the temperature of the tire equals the ambient air temperature. Tire inflation pressure must be adjusted according to total weight of cargo, rider, passenger, and accessories (cowling, side cases, etc.).


Tire air pressure (measured on cold tires)		
Load*	Front	Rear
Up to 90 kg	250 kPa (2.50 kgf/cm <sup>2</sup> , 2.50 bar)	250 kPa (2.50 kgf/cm <sup>2</sup> , 2.50 bar)
90 kg–maximum	250 kPa (2.50 kgf/cm <sup>2</sup> , 2.50 bar)	280 kPa (2.80 kgf/cm <sup>2</sup> , 2.80 bar)

Maximum load*	190 kg
---------------	--------

\* Total weight of rider, passenger, cargo and accessories

## ⚠ WARNING

Proper loading of your motorcycle is important for several characteristics of your motorcycle, such as handling, braking, performance and safety. Do not carry loosely packed items that can shift. Securely pack your heaviest items close to the center of the motorcycle, and distribute the weight evenly from side to side. Properly adjust the suspension for your load, and check the condition and pressure of your tires. **NEVER OVERLOAD YOUR MOTORCYCLE.** Make sure the total weight of the cargo, rider, passenger, and accessories (cowling, side cases, etc. if approved for this model) does not exceed the maximum load of the motorcycle. Operation of an overloaded motorcycle could cause tire damage, an accident, or even injury.



- 1. Tire sidewall
- a. Tire tread depth

## Tire inspection

The tires must be checked before each ride. If the center tread depth reaches the specified limit, if the tire has a nail or glass fragments in it, or if the sidewall is cracked, have a Yamaha dealer replace the tire immediately.

Minimum tire tread depth (front and rear)	1.6 mm
---	--------


## NOTE:

The tire tread depth limits may differ from country to country. Always comply with the local regulations.

# PERIODIC MAINTENANCE AND MINOR REPAIR

## **! WARNING**

- Have a Yamaha dealer replace excessively worn tires. Besides being illegal, operating the motorcycle with excessively worn tires decreases riding stability and can lead to loss of control.
- The replacement of all wheel- and brake-related parts, including the tires, should be left to a Yamaha dealer, who has the necessary professional knowledge and experience.



1. Tire air valve
2. Tire air valve core
3. Tire air valve cap with seal

### **Tire information**

This motorcycle is equipped with tubeless tires, tire air valves and cast wheels.

## **! WARNING**

- The front and rear tires should be of the same make and design, otherwise the handling characteristics of the motorcycle cannot be guaranteed.
- After extensive tests, only the tires listed below have been approved for this model by Yamaha Motor Co., Ltd.
- Always make sure that the valve caps are securely installed to prevent air pressure leakage.
- Use only the tire valves and valve cores listed below to avoid tire deflation during a ride.



# PERIODIC MAINTENANCE AND MINOR REPAIR

## FRONT

Manufacturer	Size	Type
Dunlop	150/80-16 71H	D404F
Bridgestone	150/80-16 71H	G705

Tire air valve	TR412
Valve core	#9000A

## REAR

Manufacturer	Size	Type
Dunlop	150/90B 15M/C 74H	D404
Bridgestone	150/90B 15M/C 74H	G702

Tire air valve	PVR59A
Valve core	#9000

## Cast wheels

To maximize the performance, durability, and safe operation of your motorcycle, note the following points regarding the specified wheels.

- The wheel rims should be checked for cracks, bends, warpage or damage before each ride. If any damage is found, have a Yamaha dealer replace the wheel. Do not attempt even the smallest repair to the wheel. A deformed or cracked wheel must be replaced.
- The wheel should be balanced whenever either the tire or wheel has been changed or replaced. An unbalanced wheel can result in poor performance, adverse handling characteristics, and a shortened tire life.
- Ride at moderate speeds after changing a tire since the tire surface must first be “broken in” for it to develop its optimal characteristics.

- After repairing or replacing the rear tire, tighten the valve stem nut and locknut to the specified torques.

### Tightening torques:


Valve stem nut:

1.6 Nm (0.16 m-kgf)

Valve stem locknut:

1.6 Nm (0.16 m-kgf)


# PERIODIC MAINTENANCE AND MINOR REPAIR



a. Clutch lever free play

## Clutch lever free play

Since this model is equipped with a hydraulic clutch, adjusting the clutch lever free play is not needed. However, it is necessary to check the clutch fluid level and check the hydraulic system for leakage before each ride. If the clutch lever free play does become excessive, and shifting becomes rough or clutch slippage occurs, causing poor acceleration, there may be air in the clutch system. If there is air in the hydraulic system, have a Yamaha dealer bleed the system before operating the motorcycle.



1. Locknut
2. Brake lever free play adjusting bolt
- c. Brake lever free play

## Adjusting the brake lever free play

The brake lever free play should measure 2–5 mm as shown. Periodically check the brake lever free play and, if necessary, adjust it as follows.


1. Loosen the locknut at the brake lever.
2. To increase the brake lever free play, turn the adjusting bolt in direction **a**. To decrease the brake lever free play, turn the adjusting bolt in direction **b**.

3. Tighten the locknut.

### **⚠ WARNING**

- After adjusting the brake lever free play, check the free play and make sure that the brake is working properly.
- A soft or spongy feeling in the brake lever can indicate the presence of air in the hydraulic system. If there is air in the hydraulic system, have a Yamaha dealer bleed the system before operating the motorcycle. Air in the hydraulic system will diminish the braking performance, which may result in loss of control and an accident.

# PERIODIC MAINTENANCE AND MINOR REPAIR



a. Distance between brake pedal and footrest

## Adjusting the brake pedal position

The top of the brake pedal should be positioned approximately 100 mm above the top of the footrest as shown. Periodically check the brake pedal position and, if necessary, have a Yamaha dealer adjust it.

### **⚠ WARNING**

A soft or spongy feeling in the brake pedal can indicate the presence of air in the hydraulic system. If there is air in the hydraulic system, have a Yamaha dealer bleed the system before operating the motorcycle. Air in the hydraulic system will diminish the braking performance, which may result in loss of control and an accident.


## Adjusting the rear brake light switch

The rear brake light switch, which is activated by the brake pedal, is properly adjusted when the brake light comes on just before braking takes effect. Since the brake light switch is a component of the cruise control system, it must be adjusted by a Yamaha dealer, who has the necessary professional knowledge and experience.


# PERIODIC MAINTENANCE AND MINOR REPAIR

## Checking the front and rear brake pads

The front and rear brake pads must be checked for wear at the intervals specified in the periodic maintenance and lubrication chart.



1. Brake pad wear indicator groove (× 3)



1. Brake pad wear indicator groove


### Front brake pads

Each front brake pad is provided with wear indicator grooves, which allow you to check the brake pad wear without having to disassemble the brake. To check the brake pad wear, check the wear indicator grooves. If a brake pad has worn to the point that the wear indicator grooves have almost disappeared, have a Yamaha dealer replace the brake pads as a set.


### Rear brake pads

Each rear brake pad is provided with a wear indicator groove, which allows you to check the brake pad wear without having to disassemble the brake. To check the brake pad wear, check the wear indicator groove. If a brake pad has worn to the point that the wear indicator groove has almost disappeared, have a Yamaha dealer replace the brake pads as a set.


# PERIODIC MAINTENANCE AND MINOR REPAIR



1. Minimum level mark



1. Minimum level mark



1. Minimum level mark

## Checking the brake and clutch fluid levels

Insufficient brake or clutch fluid may allow air to enter the brake or clutch systems, possibly causing them to become ineffective.

Before riding, check that the brake and clutch fluids are above the minimum level marks and replenish if necessary. A low brake or clutch fluid level may indicate brake or clutch system leakage and/or worn brake pads. If the brake or clutch levels are low, be sure to check the brake or clutch systems for leakage and the brake pads for wear.

Observe these precautions:

- When checking the brake and clutch fluid levels, make sure that the top of each reservoir is level.
- Use only the recommended quality brake fluid, otherwise the rubber seals may deteriorate, causing leakage and poor braking or clutch performance.

Recommended brake and clutch fluid: DOT 4 brake fluid

- Refill with the same type of brake fluid. Mixing fluids may result in a harmful chemical reaction and lead to poor braking or clutch performance.



- Be careful that water does not enter the brake or clutch fluid reservoir when refilling. Water will significantly lower the boiling point of the fluid and may result in vapor lock.
- Brake fluid may deteriorate painted surfaces or plastic parts. Always clean up spilled fluid immediately.
- As the brake pads wear, it is normal for the brake fluid level to gradually go down. However, if the brake fluid level goes down suddenly, have a Yamaha dealer check the cause.

# PERIODIC MAINTENANCE AND MINOR REPAIR

## Changing the brake and clutch fluids

Have a Yamaha dealer change the brake and clutch fluids at the intervals specified in the NOTE after the periodic maintenance and lubrication chart. In addition, have the oil seals of the brake and clutch master cylinders and calipers as well as the brake and clutch hoses replaced at the intervals listed below or whenever they are damaged or leaking.

- Oil seals: Replace every two years.
- Brake and clutch hoses: Replace every four years.




## Checking and lubricating the brake and shift pedals

The operation of the brake and shift pedals should be checked before each ride, and the pedal pivots should be lubricated if necessary.

Recommended lubricant:  
Lithium-soap-based grease  
(all-purpose grease)


# PERIODIC MAINTENANCE AND MINOR REPAIR



## Checking and lubricating the brake and clutch levers

The operation of the brake and clutch levers should be checked before each ride, and the lever pivots should be lubricated if necessary.

Recommended lubricant:  
Lithium-soap-based grease  
(all-purpose grease)



## Checking and lubricating the sidestand

The operation of the sidestand should be checked before each ride, and the sidestand pivot and metal-to-metal contact surfaces should be lubricated if necessary.

### **⚠ WARNING**

**If the sidestand does not move up and down smoothly, have a Yamaha dealer check or repair it.**

Recommended lubricant:  
Lithium-soap-based grease  
(all-purpose grease)

# PERIODIC MAINTENANCE AND MINOR REPAIR

---

## Checking the front fork


The condition and operation of the front fork must be checked as follows at the intervals specified in the periodic maintenance and lubrication chart.

### To check the condition

#### **⚠ WARNING**

**Securely support the motorcycle so that there is no danger of it falling over.**

Check the inner tubes for scratches, damage and excessive oil leakage.



### To check the operation

1. Place the motorcycle on a level surface and hold it in an upright position.
2. While applying the front brake, push down hard on the handlebars several times to check if the front fork compresses and rebounds smoothly.

#### **CAUTION:**

**If any damage is found or the front fork does not operate smoothly, have a Yamaha dealer check or repair it.**

## Checking the steering

Worn or loose steering bearings may cause danger. Therefore, the operation of the steering must be checked as follows at the intervals specified in the periodic maintenance and lubrication chart.

1. Place a stand under the engine to raise the front wheel off the ground.

#### **⚠ WARNING**


**Securely support the motorcycle so that there is no danger of it falling over.**



# PERIODIC MAINTENANCE AND MINOR REPAIR



2. Hold the lower ends of the front fork legs and try to move them forward and backward. If any free play can be felt, have a Yamaha dealer check or repair the steering.



1. Battery
2. Negative battery terminal
3. Positive battery terminal

## Battery

This motorcycle is equipped with a sealed-type (MF) battery, which does not require any maintenance. There is no need to check the electrolyte or to add distilled water.

### CAUTION:

Never attempt to remove the battery cell seals, as this would permanently damage the battery.

### ⚠ WARNING

- Electrolyte is poisonous and dangerous since it contains sulfuric acid, which causes severe burns. Avoid any contact with skin, eyes or clothing and always shield your eyes when working near batteries. In case of contact, administer the following FIRST AID.
  - **EXTERNAL:** Flush with plenty of water.
  - **INTERNAL:** Drink large quantities of water or milk and immediately call a physician.
  - **EYES:** Flush with water for 15 minutes and seek prompt medical attention.
- Batteries produce explosive hydrogen gas. Therefore, keep sparks, flames, cigarettes, etc., away from the battery and provide sufficient ventilation when charging it in an enclosed space.
- **KEEP THIS AND ALL BATTERIES OUT OF THE REACH OF CHILDREN.**

# PERIODIC MAINTENANCE AND MINOR REPAIR

## To charge the battery


Have a Yamaha dealer charge the battery as soon as possible if it seems to have discharged. Keep in mind that the battery tends to discharge more quickly if the motorcycle is equipped with optional electrical accessories.

## To store the battery

1. If the motorcycle will not be used for more than one month, remove the battery, fully charge it, and then place it in a cool, dry place.
2. If the battery will be stored for more than two months, check it at least once a month and fully charge it if necessary.
3. Fully charge the battery before installation.
4. After installation, make sure that the battery leads are properly connected to the battery terminals.

### CAUTION:

- **Always keep the battery charged. Storing a discharged battery can cause permanent battery damage.**
- **To charge a sealed-type (MF) battery, a special (constant-voltage) battery charger is required. Using a conventional battery charger will damage the battery. If you do not have access to a sealed-type (MF) battery charger, have a Yamaha dealer charge your battery.**




1. Cruise control fuse
2. Carburetor heater fuse
3. Auxiliary DC terminal fuse
4. Auxiliary DC jack fuse
5. Audio system fuse
6. Spare fuse (× 2)

## Replacing the fuses


The main fuse box is located behind panel C. (See page 7-10 for panel removal and installation procedures.) Fuse box 1 is located behind cowling A. (See page 7-6 for cowling removal and installation procedures.)

# PERIODIC MAINTENANCE AND MINOR REPAIR



1. Odometer fuse
2. Radiator fan fuse
3. Headlight fuse
4. Signaling system fuse
5. Ignition fuse
6. Spare fuse (× 2)

Fuse box 2 is located behind panel B. (See page 7-9 for panel removal and installation procedures.)



1. Main fuse
2. Spare main fuse

If a fuse is blown, replace it as follows.

1. Turn the key to “OFF” and turn off the electrical circuit in question.
2. Remove the blown fuse, and then install a new fuse of the specified amperage.

## Specified fuses:

### Fuse box 1:

Cruise control fuse:	10 A
Carburetor heater fuse:	10 A
Auxiliary DC terminal fuse:	5 A
Auxiliary DC jack fuse:	5 A
Audio system fuse:	10 A

### Fuse box 2:


Ignition fuse:	10 A
Signaling system fuse:	15 A
Headlight fuse:	15 A
Radiator fan fuse:	10 A
Odometer fuse:	10 A
Main fuse:	30 A

## CAUTION:

Do not use a fuse of a higher amperage rating than recommended to avoid causing extensive damage to the electrical system and possibly a fire.

# PERIODIC MAINTENANCE AND MINOR REPAIR

3. Turn the key to “ON” and turn on the electrical circuit in question to check if the device operates.
4. If the fuse immediately blows again, have a Yamaha dealer check the electrical system.




1. Headlight bulb cover
2. Headlight coupler

## Replacing the headlight bulb

This motorcycle is equipped with a quartz bulb headlight. If the headlight bulb burns out, replace it as follows.

1. Disconnect the headlight coupler, and then remove the headlight bulb cover.




1. Headlight bulb holder
2. Remove the headlight bulb holder by turning it counterclockwise, and then remove the defective bulb.

### **WARNING**

**Headlight bulbs get very hot. Therefore, keep flammable products away from a lit headlight bulb, and do not touch the bulb until it has cooled down.**

3. Place a new bulb into position, and then secure it with the bulb holder.

# PERIODIC MAINTENANCE AND MINOR REPAIR




1. Do not touch this area.

## CAUTION:

Do not touch the glass part of the headlight bulb to keep it free from oil, otherwise the transparency of the glass, the luminosity of the bulb, and the bulb life will be adversely affected. Thoroughly clean off any dirt and fingerprints on the headlight bulb using a cloth moistened with alcohol or thinner.


4. Install the bulb cover, and then connect the coupler.
5. Have a Yamaha dealer adjust the headlight beam if necessary.



1. Screw (× 2)

## Replacing a turn signal light bulb or the tail/brake light bulb

1. Remove the lens by removing the screws.
2. Remove the defective bulb by pushing it in and turning it counter-clockwise.



1. Screw (× 3)

3. Insert a new bulb into the socket, push it in, and then turn it clockwise until it stops.
4. Install the lens by installing the screws.

## CAUTION:

Do not overtighten the screws, otherwise the lens may break.


# PERIODIC MAINTENANCE AND MINOR REPAIR



1. Nut (× 2)

## Replacing the license plate light bulb

1. Remove the license plate light by removing the nuts.
2. Remove the license plate light lens by removing the nuts.



1. Nut (× 2)

3. Remove the defective bulb by pulling it out.
4. Insert a new bulb into the socket.
5. Install the lens by installing the nuts.
6. Install the license plate light by installing the nuts.

### **CAUTION:**

**Do not overtighten the screws, otherwise the lens may break.**

## Troubleshooting

Although Yamaha motorcycles receive a thorough inspection before shipment from the factory, trouble may occur during operation. Any problem in the fuel, compression, or ignition systems, for example, can cause poor starting and loss of power.

The following troubleshooting charts represent quick and easy procedures for checking these vital systems yourself. However, should your motorcycle require any repair, take it to a Yamaha dealer, whose skilled technicians have the necessary tools, experience, and know-how to service the motorcycle properly.

Use only genuine Yamaha replacement parts. Imitation parts may look like Yamaha parts, but they are often inferior, have a shorter service life and can lead to expensive repair bills.

# PERIODIC MAINTENANCE AND MINOR REPAIR

## Troubleshooting charts


### Starting problems or poor engine performance




**WARNING**

**Keep away open flames and do not smoke while checking or working on the fuel system.**


#### 1. Fuel




#### 2. Compression



#### 3. Ignition



#### 4. Battery




# PERIODIC MAINTENANCE AND MINOR REPAIR

## Engine overheating

### **⚠ WARNING**

- Do not remove the radiator cap when the engine and radiator are hot. Scalding hot fluid and steam may be blown out under pressure, which could cause serious injury. Be sure to wait until the engine has cooled.
- After removing the radiator cap retaining bolt, place a thick rag, like a towel, over the radiator cap, and then slowly rotate the cap counterclockwise to the detent to allow any residual pressure to escape. When the hissing sound has stopped, press down on the cap while turning it counterclockwise, and then remove the cap.



### **NOTE:**

If coolant is not available, tap water can be temporarily used instead, provided that it is changed to the recommended coolant as soon as possible.




# MOTORCYCLE CARE AND STORAGE

---

Care .....	8-1
Storage .....	8-4

# MOTORCYCLE CARE AND STORAGE



## Care

While the open design of a motorcycle reveals the attractiveness of the technology, it also makes it more vulnerable. Rust and corrosion can develop even if high-quality components are used. A rusty exhaust pipe may go unnoticed on a car, however, it detracts from the overall appearance of a motorcycle. Frequent and proper care does not only comply with the terms of the warranty, but it will also keep your motorcycle looking good, extend its life and optimize its performance.

## Before cleaning

1. Cover the muffler outlets with plastic bags after the engine has cooled down.
2. Make sure that all caps and covers as well as all electrical couplers and connectors, including the spark plug caps, are tightly installed.
3. Remove extremely stubborn dirt, like oil burnt onto the crankcase, with a degreasing agent and a brush, but never apply such products onto seals, gaskets and wheel axles. Always rinse the dirt and degreaser off with water.

## Cleaning

### CAUTION:

- Avoid using strong acidic wheel cleaners, especially on spoked wheels. If such products are used on hard-to-remove dirt, do not leave the cleaner on the affected area any longer than instructed. Also, thoroughly rinse the area off with water, immediately dry it, and then apply a corrosion protection spray.
- Improper cleaning can damage windshields, cowlings, panels and other plastic parts. Use only a soft, clean cloth or sponge with mild detergent and water to clean plastic.
- Do not use any harsh chemical products on plastic parts. Be sure to avoid using cloths or sponges which have been in contact with strong or abrasive cleaning products, solvent or

# MOTORCYCLE CARE AND STORAGE

---

thinner, fuel (gasoline), rust removers or inhibitors, brake fluid, antifreeze or electrolyte.

- Do not use high-pressure washers or steam-jet cleaners since they cause water seepage and deterioration in the following areas: seals (of wheel and swing-arm bearings, fork and brakes), electric components (couplers, connectors, instruments, switches, lights, audio system and speakers), sidecases, travel trunk, breather hoses and vents.

- For motorcycles equipped with a windshield: Do not use strong cleaners or hard sponges as they will cause dulling or scratching. Some cleaning compounds for plastic may leave scratches on the windshield. Test the product on a small hidden part of the windshield to make sure that it does not leave any marks. If the windshield is scratched, use a quality plastic polishing compound after washing.

---

## After normal use

Remove dirt with warm water, a mild detergent, and a soft, clean sponge, and then rinse thoroughly with clean water. Use a toothbrush or bottlebrush for hard-to-reach areas. Stubborn dirt and insects will come off more easily if the area is covered with a wet cloth for a few minutes before cleaning.

After riding in the rain, near the sea or on salt-sprayed roads

Since sea salt or salt sprayed on roads during winter are extremely corrosive in combination with water, carry out the following steps after each ride in the rain, near the sea or on salt-sprayed roads.

**NOTE:** \_\_\_\_\_  
Salt sprayed on roads in the winter may remain well into spring.

1. Clean the motorcycle with cold water and a mild detergent, after the engine has cooled down.

**CAUTION:** \_\_\_\_\_  
**Do not use warm water since it increases the corrosive action of the salt.**

2. Apply a corrosion protection spray on all metal, including chrome- and nickel-plated, surfaces to prevent corrosion.

# MOTORCYCLE CARE AND STORAGE

---

---

## After cleaning

1. Dry the motorcycle with a chamois or an absorbing cloth.
2. Use a chrome polish to shine chrome, aluminum and stainless-steel parts, including the exhaust system. (Even the thermally induced discoloring of stainless-steel exhaust systems can be removed through polishing.)
3. To prevent corrosion, it is recommended to apply a corrosion protection spray on all metal, including chrome- and nickel-plated, surfaces.
4. Use spray oil as a universal cleaner to remove any remaining dirt.
5. Touch up minor paint damage caused by stones, etc.
6. Wax all painted surfaces.
7. Let the motorcycle dry completely before storing or covering it.

## WARNING

- **Make sure that there is no oil or wax on the brakes or tires. If necessary, clean the brake discs and brake linings with a regular brake disc cleaner or acetone, and wash the tires with warm water and a mild detergent.**
  - **Before operating the motorcycle test its braking performance and cornering behavior.**
- 

## CAUTION:


- **Apply spray oil and wax sparingly and make sure to wipe off any excess.**
  - **Never apply oil or wax to any rubber and plastic parts, but treat them with a suitable care product.**
  - **Avoid using abrasive polishing compounds as they will wear away the paint.**
- 

## NOTE:

Consult a Yamaha dealer for advice on what products to use.

---

# MOTORCYCLE CARE AND STORAGE



## Storage

### Short-term

Always store your motorcycle in a cool, dry place and, if necessary, protect it against dust with a porous cover.

### CAUTION:

- **Storing the motorcycle in a poorly ventilated room or covering it with a tarp, while it is still wet, will allow water and humidity to seep in and cause rust.**

- **To prevent corrosion, avoid damp cellars, stables (because of the presence of ammonia) and areas where strong chemicals are stored.**

### Long-term

Before storing your motorcycle for several months:

1. Follow all the instructions in the “Care” section of this chapter.
2. For motorcycles equipped with a fuel cock that has an “OFF” position: Turn the fuel cock lever to “OFF”.
3. Drain the carburetor float chamber by loosening the drain bolt; this will prevent fuel deposits from building up. Pour the drained fuel into the fuel tank.
4. Fill up the fuel tank and add fuel stabilizer (if available) to prevent the fuel tank from rusting and the fuel from deteriorating.
5. Perform the following steps to protect the cylinders, piston rings, etc. from corrosion.
  - a. Remove the spark plug caps and spark plugs.
  - b. Pour a teaspoonful of engine oil into each spark plug bore.
  - c. Install the spark plug caps onto the spark plugs, and then place the spark plugs on the cylinder head so that the electrodes are grounded. (This will limit sparking during the next step.)
  - d. Turn the engine over several times with the starter. (This will coat the cylinder walls with oil.)
  - e. Remove the spark plug caps from the spark plugs, and then install the spark plugs and the spark plug caps.

# MOTORCYCLE CARE AND STORAGE

---

---

## WARNING

To prevent damage or injury from sparking, make sure to ground the spark plug electrodes while turning the engine over.

---

6. Lubricate all control cables and the pivoting points of all levers and pedals as well as of the sidestand/centerstand.
7. Check and, if necessary, correct the tire air pressure, and then lift the motorcycle so that both of its wheels are off the ground. Alternatively, turn the wheels a little every month in order to prevent the tires from becoming degraded in one spot.
8. Cover the muffler outlets with plastic bags to prevent moisture from entering them.

9. Remove the battery and fully charge it. Store it in a cool, dry place and charge it once a month. Do not store the battery in an excessively cold or warm place (less than 0 °C or more than 30 °C). For more information on storing the battery, see page 7-33.

**NOTE:** \_\_\_\_\_  
Make any necessary repairs before storing the motorcycle.

---

Specifications ..... 9-1  
Conversion table ..... 9-5


# SPECIFICATIONS

## Specifications

<b>Model</b>	<b>XVZ1300TF</b>
<b>Dimensions</b>	
Overall length	2,705 mm
Overall width	900 mm
Overall height	1,565 mm (except for D) 1,380 mm (for D)
Seat height	750 mm
Wheelbase	1,705 mm
Minimum ground clearance	155 mm
Minimum turning radius	3,500 mm
<b>Basic weight (with oil and full fuel tank)</b>	<b>394 kg</b>
<b>Engine</b>	
Engine type	Liquid-cooled 4-stroke, DOHC
Cylinder arrangement	V-type, 4-cylinder
Displacement	1,294 cm <sup>3</sup>
Bore × stroke	79 × 66 mm
Compression ratio	10:1
Starting system	Electric starter
Lubrication system	Wet sump

## Engine oil

### Type



Recommended engine oil classification

API Service SE, SF, SG or higher

### CAUTION:

**Be sure to use motor oils that do not contain anti-friction modifiers. Passenger car motor oils (often labeled "ENERGY CONSERVING II") contain anti-friction additives which will cause clutch and/or starter clutch slippage, resulting in reduced component life and poor engine performance.**

### Quantity

Without oil filter cartridge replacement	3.5 L
With oil filter cartridge replacement	3.7 L
Total amount (dry engine)	4.3 L



# SPECIFICATIONS

## Final gear oil

Type	SAE80 API "GL-4" hypoid gear oil
Quantity	0.2 L

## Cooling system capacity (total amount)

3.5 L

## Air filter

Dry type element

## Fuel

Type	Regular unleaded gasoline
Fuel tank capacity	22.5 L
Fuel reserve amount	3.5 L

## Carburetor

Manufacturer	MIKUNI
Model × quantity	BDSR32 × 4

## Spark plug

Manufacturer/model	NGK / DPR8EA-9 or DENSO / X24EPR-U9
Gap	0.8–0.9 mm

## Clutch type

Wet, multiple-disc

## Transmission

Primary reduction system	Spur gear
Primary reduction ratio	1.776
Secondary reduction system	Shaft drive
Secondary reduction ratio	2.567
Transmission type	Constant-mesh, 5-speed

## Operation

Left foot

## Gear ratio

1st	2.529
2nd	1.632
3rd	1.200
4th	0.960
5th	0.786

## Chassis

Frame type	Double cradle
Caster angle	29.17°
Trail	152 mm

## Tire

### Front

Type	Tubeless tire
Size	150/80-16 71H
Manufacturer/ model	Dunlop / D404F Bridgestone / G705

### Rear

Type	Tubeless tire
Size	150/90B15M/C 74H
Manufacturer/ model	Dunlop / D404 Bridgestone / G702

# SPECIFICATIONS

Maximum load*	190 kg
Tire air pressure (measured on cold tires)	
Up to 90 kg*	
Front	250 kPa (2.50 kgf/cm <sup>2</sup> , 2.50 bar)
Rear	250 kPa (2.50 kgf/cm <sup>2</sup> , 2.50 bar)
90 kg–maximum*	
Front	250 kPa (2.50 kgf/cm <sup>2</sup> , 2.50 bar)
Rear	280 kPa (2.80 kgf/cm <sup>2</sup> , 2.80 bar)

\* Total weight of rider, passenger, cargo and accessories

## Wheels

Front		
	Type	Cast wheel
	Size	16 × MT 3.50
Rear		
	Type	Cast wheel
	Size	15M/C × MT 4.00

## Brakes

Front		
	Type	Dual disc brake
	Operation	Right hand
	Fluid	DOT 4

Rear		
	Type	Single disc brake
	Operation	Right foot
	Fluid	DOT 4

## Suspension

Front	Telescopic fork
Rear	Swingarm (link suspension)

## Spring/shock absorber

Front	Coil-air spring / oil damper
Rear	Coil-air spring / oil damper

## Wheel travel

Front	140 mm
Rear	105 mm

## Electrical

Ignition system	T.C.I. (digital)
Charging system	
Type	A.C. magneto
Standard output	14 V, 29 A @ 5,000 r/min
Battery	
Model	YTX20L-BS
Voltage, capacity	12 V, 18 Ah

## Headlight type

Quartz bulb (halogen)

### Bulb voltage, wattage × quantity

Headlight	12 V, 60/55 W × 1
Tail/brake light	12 V, 5/21 W × 1
Turn signal light	12 V, 21 W × 4
Auxiliary light	12 V, 4 W × 1
License light	12 V, 5 W × 2
Neutral indicator light	12 V, 1.7 W × 1
High beam indicator light	12 V, 1.7 W × 1
Oil level warning light	12 V, 1.7 W × 1
Turn signal indicator light	12 V, 1.7 W × 2
Fuel level warning light	14 V, 3 W × 1
Coolant temperature warning light	12 V, 1.7 W × 1
Engine trouble warning light	12 V, 1.7 W × 1
Overdrive indicator light	12 V, 1.7 W × 1
Cruise control "SET" indicator light	12 V, 1.7 W × 1
Cruise control "RES" indicator light	12 V, 1.7 W × 1
Cruise control "ON" indicator light	12 V, 1.7 W × 1

### Audio system amplifier

Output power	
Speaker	14 W × 4
Headset	1 W × 2
Auto-volume range	5 steps
Output impedance	
Speaker	4 Ω
Headset	8–16 Ω

### Fuses

Main fuse	30 A
Headlight fuse	15 A
Signaling system fuse	15 A
Ignition fuse	10 A
Radiator fan fuse	10 A
Odometer fuse	10 A
Cruise control fuse	10 A
Carburetor heater fuse	10 A
Audio system fuse	10 A
Auxiliary DC jack fuse	5 A
Auxiliary DC terminal fuse	5 A

# SPECIFICATIONS

## Conversion table

All specification data in this manual are listed in SI and METRIC UNITS.

Use this table to convert METRIC unit values to IMPERIAL unit values.

Example:

METRIC VALUE	CONVERSION FACTOR		IMPERIAL VALUE
2 mm	× 0.03937	=	0.08 in

Conversion table

METRIC SYSTEM TO IMPERIAL SYSTEM			
	Metric unit	Conversion factor	Imperial unit
Torque	m-kgf	× 7.233	ft-lb
	m-kgf	× 86.794	in-lb
	cm-kgf	× 0.0723	ft-lb
	cm-kgf	× 0.8679	in-lb
Weight	kg	× 2.205	lb
	g	× 0.03527	oz
Speed	km/h	× 0.6214	mi/h
Distance	km	× 0.6214	mi
	m	× 3.281	ft
	m	× 1.094	yd
	cm	× 0.3937	in
	mm	× 0.03937	in
Volume, Capacity	cc (cm <sup>3</sup> )	× 0.03527	oz (IMP liq.)
	cc (cm <sup>3</sup> )	× 0.06102	cu-in
	L (liter)	× 0.8799	qt (IMP liq.)
	L (liter)	× 0.2199	gal (IMP liq.)
Miscellaneous	kgf/mm	× 55.997	lb/in
	kgf/cm <sup>2</sup>	× 14.2234	psi (lb/in <sup>2</sup> )
	°C	× 1.8 + 32	°F

Identification numbers .....	10-1
Key identification number .....	10-1
Vehicle identification number .....	10-1
Model label .....	10-2

# CONSUMER INFORMATION


## Identification numbers

Record the key identification number, vehicle identification number and model label information in the spaces provided below for assistance when ordering spare parts from a Yamaha dealer or for reference in case the vehicle is stolen.


1. KEY IDENTIFICATION NUMBER:

2. VEHICLE IDENTIFICATION NUMBER:

3. MODEL LABEL INFORMATION:



1. Key identification number



1. Vehicle identification number

### Key identification number


The key identification number is stamped into the key tag. Record this number in the space provided and use it for reference when ordering a new key.

### Vehicle identification number

The vehicle identification number is stamped into the steering head pipe. Record this number in the space provided.

### NOTE:

The vehicle identification number is used to identify your motorcycle and may be used to register your motorcycle with the licensing authority in your area.



1. Model label

## **Model label**

The model label is affixed to the frame under the rider seat. (See page 3-15 for rider seat removal and installation procedures.) Record the information on this label in the space provided. This information will be needed when ordering spare parts from a Yamaha dealer.

# INDEX

## A

- Air filter elements, cleaning ..... 7-17
- Anti-theft alarm ..... 3-8
- Audio settings (basic)..... 4-5
- Audio settings (modes) ..... 4-5
- Audio system parts, location of ..... 4-1
- Auxiliary audio source ..... 4-18
- Auxiliary DC jack and terminals ..... 3-24

## B

- Battery ..... 7-32
- Brake and clutch fluid levels,  
checking ..... 7-28
- Brake and clutch fluids, changing..... 7-29
- Brake and clutch levers, checking and  
lubricating ..... 7-30
- Brake and shift pedals, checking and  
lubricating ..... 7-29
- Brake lever..... 3-11
- Brake lever free play, adjusting ..... 7-25
- Brake light switch (rear), adjusting ..... 7-26
- Brake pads, checking..... 7-27
- Brake pedal..... 3-11
- Brake pedal position, adjusting ..... 7-26

## C

- Carburetors, adjusting ..... 7-19
- Care..... 8-1
- Cassette deck operation ..... 4-9
- CD changer operation ..... 4-17
- Clutch lever ..... 3-10
- Clutch lever free play ..... 7-25
- Conversion table ..... 9-5
- Coolant level, checking ..... 7-15

- Coolant temperature warning light ..... 3-4
- Cowlings and panels, removing and  
installing ..... 7-6
- Cruise control indicator lights ..... 3-4
- Cruise control switches ..... 3-10
- Cruise control system ..... 3-6

## D

- Dimmer switch ..... 3-9

## E

- Engine break-in ..... 6-5
- Engine oil and oil filter cartridge ..... 7-12
- Engine stop switch..... 3-9
- Engine trouble warning light ..... 3-3

## F

- Final gear oil ..... 7-15
- Front fork, adjusting ..... 3-19
- Front fork, checking ..... 7-31
- Fuel ..... 3-12
- Fuel cock..... 3-13
- Fuel consumption, tips for reducing ..... 6-4
- Fuel gauge ..... 3-8
- Fuel level warning light ..... 3-4
- Fuel tank breather hose..... 3-13
- Fuel tank cap..... 3-11
- Fuses, replacing ..... 7-33

## H

- Handlebar switches ..... 3-9
- Headlight bulb, replacing ..... 7-35
- Headsets ..... 4-2
- Helmet holders ..... 3-15
- High beam indicator light ..... 3-3

- Horn switch ..... 3-9

## I

- Identification numbers ..... 10-1
- Idling speed, adjusting ..... 7-20
- Ignition circuit cut-off system ..... 3-22
- Indicator and warning lights ..... 3-3

## K

- Key identification number ..... 10-1

## L

- License plate light bulb, replacing..... 7-37
- Light switch ..... 3-9

## M

- Main switch/steering lock ..... 3-1
- Model label ..... 10-2

## N

- Neutral indicator light ..... 3-4

## O

- Oil level warning light ..... 3-3
- Overdrive indicator light..... 3-3

## P

- Parking..... 6-6
- Part locations ..... 2-1
- Pass switch ..... 3-9
- Periodic maintenance and lubrication  
chart ..... 7-3
- Pre-operation check list..... 5-1

## R

- Radio operation..... 4-12
- Rider seat ..... 3-15



## S

Safety information.....	1-1
Shifting .....	6-3
Shift pedal .....	3-10
Shift points (for Switzerland only).....	6-4
Shock absorber assembly, adjusting .....	3-20
Side cases and travel trunk.....	3-16
Sidestand .....	3-21
Sidestand, checking and lubricating.....	7-30
Sound control unit.....	4-3
Spark plugs, checking .....	7-11
Specifications .....	9-1
Speedometer unit .....	3-5
Starter (choke) knob .....	3-14
Starting a warm engine.....	6-3
Starting the engine .....	6-1
Start switch.....	3-10
Steering, checking .....	7-31
Steering, locking with a padlock.....	3-14
Storage.....	8-4

## T

Throttle cable free play, adjusting .....	7-21
Tires .....	7-21
Tool kit.....	7-1
Troubleshooting.....	7-37
Troubleshooting charts .....	7-38
Turn signal indicator lights .....	3-3
Turn signal light or tail/brake light bulb, replacing .....	7-36
Turn signal switch.....	3-9

## V


Valve clearance, adjusting .....	7-21
Vehicle identification number.....	10-1

## W

Wheels.....	7-24
-------------	------







PRINTED ON RECYCLED PAPER  
5JC-28199-E2



PRINTED IN JAPAN  
2001 · 1 - 0.3 × 1 CR  
(E)